

# ARM® Developer Suite

Version 1.2

## Debug Target Guide

**ARM**

# ARM Developer Suite

## Debug Target Guide

Copyright © 1999-2001 ARM Limited. All rights reserved.

### Release Information

The following changes have been made to this book.

Change History		
Date	Issue	Change
October 1999	A	Release 1.0
March 2000	B	Release 1.0.1
November 2000	C	Release 1.1
November 2001	D	Release 1.2

### Proprietary Notice

Words and logos marked with ® or ™ are registered trademarks or trademarks owned by ARM Limited. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM Limited shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

# Contents

## ARM Developer Suite Debug Target Guide

	<b>Preface</b>	
	About this book .....	vi
	Feedback .....	x
<b>Chapter 1</b>	<b>Introduction</b>	
	1.1 Debug target overview .....	1-2
<b>Chapter 2</b>	<b>ARMulator Basics</b>	
	2.1 About ARMulator .....	2-2
	2.2 ARMulator components .....	2-3
	2.3 Tracer .....	2-5
	2.4 Profiler .....	2-12
	2.5 ARMulator cycle types .....	2-14
	2.6 Pagetable module .....	2-19
	2.7 Default memory model .....	2-26
	2.8 Memory modelling with mapfiles .....	2-27
	2.9 Semihosting .....	2-31
	2.10 Peripheral models .....	2-32
<b>Chapter 3</b>	<b>Writing ARMulator models</b>	
	3.1 The ARMulator extension kit .....	3-2
	3.2 Writing a new peripheral model .....	3-5

3.3	Building a new model .....	3-7
3.4	Configuring ARMulator to use a new model .....	3-8
3.5	Configuring ARMulator to disable a model .....	3-10

## Chapter 4

### ARMulator Reference

4.1	ARMulator models .....	4-2
4.2	Communicating with the core .....	4-3
4.3	Basic model interface .....	4-12
4.4	Coprocessor model interface .....	4-15
4.5	Exceptions .....	4-26
4.6	Events .....	4-29
4.7	Handlers .....	4-33
4.8	Memory access functions .....	4-38
4.9	Event scheduling functions .....	4-40
4.10	General purpose functions .....	4-41
4.11	Accessing the debugger .....	4-52
4.12	Tracer .....	4-57
4.13	Map files .....	4-59
4.14	ARMulator configuration files .....	4-63
4.15	ToolConf .....	4-68
4.16	Reference peripherals .....	4-75

## Chapter 5

### Semihosting

5.1	Semihosting .....	5-2
5.2	Semihosting implementation .....	5-5
5.3	Adding an application SWI handler .....	5-8
5.4	Semihosting SWIs .....	5-11
5.5	Debug agent interaction SWIs .....	5-27

### Glossary

# Preface

This preface introduces the ARM debug targets and their reference documentation. It contains the following sections:

- *About this book* on page vi
- *Feedback* on page x.

## About this book

This book provides reference information for the *ARM Developer Suite* (ADS). It describes:

- ARMulator®, the ARM processor simulator
- Semihosting SWIs, the means for your ARM programs to access facilities on your host computer.

## Intended audience

This book is written for all developers who are using the ARM debuggers, armsd and AXD. It assumes that you are an experienced software developer, and that you are familiar with the ARM development tools as described in *Getting Started*.

## Using this book

This book is organized into the following chapters:

### Chapter 1 *Introduction*

Read this chapter for an introduction to the material in this book, and a summary description of the range of ARM debug targets.

### Chapter 2 *ARMulator Basics*

Read this chapter for a description of ARMulator, the ARM instruction set simulator.

### Chapter 3 *Writing ARMulator models*

Read this chapter for help in writing your own extensions and modifications to ARMulator.

### Chapter 4 *ARMulator Reference*

This chapter provides further details to help you use ARMulator.

### Chapter 5 *Semihosting*

Read this chapter for information about how to access facilities on the host computer from your ARM programs.

## Typographical conventions

The following typographical conventions are used in this book:

<i>italic</i>	Highlights important notes, introduces special terminology, denotes internal cross-references, and citations.
<b>bold</b>	Highlights interface elements, such as menu names. Also used for emphasis in descriptive lists, where appropriate, and for ARM processor signal names.
<code>monospace</code>	Denotes text that can be entered at the keyboard, such as commands, file and program names, and source code.
<u>monospace</u>	Denotes a permitted abbreviation for a command or option. The underlined text can be entered instead of the full command or option name.
<code>monospace italic</code>	Denotes arguments to commands and functions where the argument is to be replaced by a specific value.
<code>monospace bold</code>	Denotes language keywords when used outside example code.

## Further reading

This section lists publications from both ARM Limited and third parties that provide additional information on developing code for the ARM family of processors.

ARM periodically provides updates and corrections to its documentation. See <http://www.arm.com> for current errata sheets and addenda.

See also the ARM Frequently Asked Questions list at: <http://www.arm.com/DevSupp/Sales+Support/faq.html>

## ARM publications

This book contains information that is specific to the versions of ARMulator and the semihosting SWIs supplied with the *ARM Developer Suite* (ADS). Refer to the following books in the ADS document suite for information on other components of ADS:

- *ADS Installation and License Management Guide* (ARM DUI 0139)
- *Getting Started* (ARM DUI 0064)
- *ADS Assembler Guide* (ARM DUI 0068)
- *ADS Compilers and Libraries Guide* (ARM DUI 0067)
- *ADS Linker and Utilities Guide* (ARM DUI 0151)
- *CodeWarrior IDE Guide* (ARM DUI 0065)
- *AXD and armsd Debuggers Guide* (ARM DUI 0066)
- *ADS Developer Guide* (ARM DUI 0056)
- *ARM Applications Library Programmer's Guide* (ARM DUI 0081).

The following additional documentation is provided with the ARM Developer Suite:

- *ARM Architecture Reference Manual* (ARM DDI 0100). This is supplied in DynaText format as part of the online books, and in PDF format in `install_directory\PDF\ARM-DDI0100B_armarm.pdf`.
- *ARM ELF specification* (SWS ESPC 0003). This is supplied in PDF format in `install_directory\PDF\specs\ARMELF.pdf`.
- *TIS DWARF 2 specification*. This is supplied in PDF format in `install_directory\PDF\specs\TIS-DWARF2.pdf`.



- *ARM/Thumb® Procedure Call Specification* (SWS ESPC 0002). This is supplied in PDF format in *install\_directory\PDF\specs\ATPCS.pdf*.

In addition, refer to the following documentation for specific information relating to ARM products:

- *ARM Reference Peripheral Specification* (ARM DDI 0062)
- the ARM datasheet or technical reference manual for your hardware device.

## Feedback

ARM Limited welcomes feedback on both the ARM Developer Suite, and its documentation.

### Feedback on the ARM Developer Suite

If you have any problems with the ARM Developer Suite, please contact your supplier. To your supplier provide a rapid and useful response, please give:

- details of the release you are using
- details of the platform you are running on, such as the hardware platform, operating system type and version
- a small stand-alone sample of code that reproduces the problem
- a clear explanation of what you expected to happen, and what actually happened
- the commands you used, including any command-line options
- sample output illustrating the problem
- the version string of the tool, including the version number and date.

### Feedback on this book

If you have any problems with this book, please send email to [errata@arm.com](mailto:errata@arm.com) giving:

- the document title
- the document number
- the page number(s) to which you comments apply
- a concise explanation of your comments.

General suggestions for additions and improvements are also welcome.

# Chapter 1

## Introduction

This chapter introduces the debug support facilities provided in the ADS version 1.2. It contains the following section:

- *Debug target overview* on page 1-2.

## 1.1 Debug target overview

You can debug your prototype software using either of the debuggers described in *AXD and armsd Debuggers Guide*, or a third party debugger. The debugger runs on your *host computer*. It is connected to a *target system* that your prototype software runs on.

Your target system can be any one of:

- a software simulator, ARMulator, simulating ARM hardware
- an ARM evaluation or development board
- a third-party ARM-based development board
- ARM-based hardware of your own design.

### 1.1.1 ARMulator

A software simulator, ARMulator, is supplied with ADS. ARMulator runs on the same host computer as the debugger. It includes facilities for communication with the debugger.

ARMulator is an instruction set simulator. It simulates the instruction sets and architecture of ARM processors, together with a memory system and peripherals. You can extend it to simulate other peripherals and custom memory systems (see Chapter 3 *Writing ARMulator models*).

You can use ARMulator for software development and for benchmarking ARM-targeted software. It models the instruction set and counts cycles. There are limits to the accuracy of benchmarking, see *Accuracy* on page 2-2.

This book is mainly concerned with the ARMulator.

### 1.1.2 Hardware targets

You can use one of three different arrangements for a debugger to communicate with a hardware target system:

- You can run a debug monitor, such as Angel or RealMonitor, on the target system, in addition to your application code. The debug monitor handles communication with the debugger.
- If your target processor has EmbeddedICE® logic, you can set:
  - breakpoints in your code
  - watchpoints in memory.

Execution halts at breakpoints, or when watchpoints are accessed. You can then examine the state of your system, alter it, and restart it. In this way you can avoid having any code other than your prototype software running on your target system.

- If your target system has an Embedded Trace Macrocell, you can examine the operation of your system while it is running.

For details see the documentation accompanying the hardware.

### 1.1.3 Semihosting

You can use the I/O facilities of the host computer, instead of providing the facilities on your target system. This is called *semihosting* (see Chapter 5 *Semihosting*).

C and C++ code uses semihosting facilities by default.

To access semihosting facilities from assembly code, use semihosting *Software Interrupts* (SWIs). Any of the following intercept semihosting SWIs and request service from the host computer:

- ARMulator
- your debug monitor
- Multi-ICE®.



# Chapter 2

## ARMuIator Basics

This chapter describes ARMuIator, a collection of programs that provide software simulation of ARM processors. It contains the following sections:

- *About ARMuIator* on page 2-2
- *ARMuIator components* on page 2-3
- *Tracer* on page 2-5
- *Profiler* on page 2-12
- *ARMuIator cycle types* on page 2-14
- *Paetable module* on page 2-19
- *Default memory model* on page 2-26
- *Memory modelling with mapfiles* on page 2-27
- *Peripheral models* on page 2-32.

## 2.1 About ARMulator

ARMulator is an instruction set simulator. It simulates the instruction sets and architecture of various ARM processors. To run software on ARMulator, you must access it either through the ARM symbolic debugger, *armsd*, through the ARM GUI debugger, *AXD*, or through a third party debugger. See *AXD and armsd Debuggers Guide* for details.

ARMulator is suited to software development and benchmarking ARM-targeted software. It models the instruction set and counts cycles (see *ARMulator cycle types* on page 2-14). There are limits to the accuracy of benchmarking and cycle counting, see *Accuracy*.

ARMulator provides all the facilities needed to allow complete C or C++ programs to run on the simulated system. See also Chapter 5 *Semihosting* for information on the C library semihosting SWIs supported by ARMulator.

### 2.1.1 Accuracy

ARMulator is not 100% cycle accurate, because it is not based on the actual processor design. In general, models of the less complex, uncached ARM processor cores are cycle accurate, but models of the cached variants might not correspond exactly with the actual hardware.

ARMulator is suitable for use as a software development tool for system design, but a hardware model must be used if 100% accuracy is required.

You can use ARMulator for benchmarking if either:

- the core you are modelling does not have a cache
- you are only interested in approximate comparisons.

ARMulator does not model Asynchronous Mode on cached cores. If you set the control bits in CP15 to specify Asynchronous Mode, ARMulator gives a warning:

Set to Asynch mode, WARNING this is not supported

You can continue debugging, but ARMulator behaves exactly as it does in Synchronous Mode.



## 2.2 ARMulator components

ARMulator consists of a series of modules, implemented as *Dynamic Link Libraries* (.dll files) for Windows, or as *Shared Objects* (.so files for Linux or Solaris, .sl files for HP/UX).

The main modules are:

- a model of the ARM processor core
- a model of the memory used by the processor.

There are alternative predefined modules for each of these parts. You can select the combination of processor and memory model you want to use.

One of the predefined memory models, `mapfile`, allows you to specify a simulated memory system in detail. `mapfile` allows you to specify narrow memories and wait states (see *Memory modelling with mapfiles* on page 2-27).

In addition there are predefined modules which you can use to:

- model additional hardware, such as a coprocessor or peripherals
- model pre-installed software, such as a C library, semihosting SWI handler, or an operating system
- extract debugging or benchmarking information (see *Tracer* on page 2-5 and *Profiler* on page 2-12).

You can use different combinations of predefined modules and different memory maps (see *Configuring ARMulator* on page 2-4).

You can write your own modules, or edit copies of the predefined ones, if the modules provided do not meet your requirements. For example:

- to model a different peripheral, coprocessor, or operating system
- to model a different memory system
- to provide additional debugging or benchmarking information.

The source code of some modules is supplied. You can use these as examples to help you write your own modules (see Chapter 3 *Writing ARMulator models*).

## 2.2.1 Configuring ARMulator

You can configure some of the details of ARMulator from `armsd`, or from your GUI debugger (see *AXD and armsd Debuggers Guide*). The current configurations are announced in the debugger startup banner.

To make other configuration adjustments you must edit copies of `.ami` files. Six `.ami` files are supplied with ADS:

- `bustypes.ami`
- `default.ami`
- `example1.ami`
- `peripherals.ami`
- `processors.ami`
- `vfp.ami`

These files are located in:

- `install_directory\Bin` for Windows installations
- `install_directory/linux86/Bin` for Linux installations
- `install_directory/solaris/Bin` for Solaris installations
- `install_directory/cchppa/Bin` for HP/UX installations.

If you write any ARMulator models of your own, you can produce additional `.ami` files to allow your models to be configured. See *ARMulator configuration files* on page 4-63 for details of how to do this.

When ARMulator is started by a debugger, it reads all the `.ami` files on any of the paths it finds in the environment variable `armconf`. This is initially set up to point to `install_directory\Bin`.

The following sections describe each of the predefined modules in turn, and how they can be configured.

### ———— Note —————

Where there is a conflict between configuration settings in a `.ami` file, and settings you have made from AXD, the AXD settings take precedence.

---

## 2.3 Tracer

You can use Tracer to trace instructions, memory accesses, and events. The configuration file `peripherals.ami` controls what is traced (see *ARMulator configuration files* on page 4-63).

This section contains the following subsections:

- *Debugger support for tracing*
- *Interpreting trace file output* on page 2-6
- *Configuring Tracer* on page 2-10.

### 2.3.1 Debugger support for tracing

There is no direct debugger support for tracing. Instead, Tracer uses bit 4 of the RDI logging level (`$rdi_log`) variable to enable or disable tracing.

#### Using AXD

Select **System Views** → **Debugger Internals** → **Internal Variables**, and then double-click on the `$rdi_log` value to edit it:

- to enable tracing, set `$rdi_log` to `0x00000010`
- to disable tracing, set `$rdi_log` to `0x00000000`.

#### Using armsd

Enter the following at the command prompt:

- to enable tracing under armsd, type `$rdi_log=16`
- to disable tracing, type `$rdi_log=0`.

### 2.3.2 Interpreting trace file output

This section describes how you interpret the output from Tracer.

#### Example of a trace file

The following example shows part of a trace file:

```
Date: Thu Aug  9 16:41:36 2001
Source: Armul
Options: Trace Instructions (Disassemble) Trace Memory Cycles
```

```
BNR40___ A0000000 00000C1E
BNR80___ 00008000 E28F8090 E898000F
BSR80___ 00008008 E0800008 E0811008
BSR80___ 00008010 E0822008 E0833008
BSR80___ 00008018 E240B001 E242C001
MNR40___ 00008000 E28F8090
IT 00008000 e28f8090 ADD      r8,pc,#0x90 ; #0x8098
MNR40___ 00008004 E898000F
IT 00008004 e898000f LDMIA    r8,{r0-r3}
BNR40___ A0000000 00000C1E
BNR80___ 00008098 00007804 00007828
BSR80___ 00008080 10844009 E3C44003
BSR80___ 00008088 E2555004 24847004
BSR80___ 00008090 8AFFFFF2 EAF2FF2
MNR8____ 00008098 00007804 00007828
BNR80___ 000080A0 00007828 00007840
BSR80___ 000080A8 E3A00840 E1A0F00E
BSR80___ 000080B0 E92D400C E28F0014
BSR80___ 000080B8 E5901000 E5900004
MNR8____ 000080A0 00007828 00007840
MNR40___ 00008008 E0800008
IT 00008008 e0800008 ADD      r0,r0,r8
MNR40___ 0000800C E0811008
IT 0000800C e0811008 ADD      r1,r1,r8
MNR40___ 00008010 E0822008
```

In a trace file, there can be five types of line:

- *Trace memory (M lines)* on page 2-7
- *Trace instructions (I lines)* on page 2-8
- *Trace events (E lines)* on page 2-8
- *Trace registers (R lines)* on page 2-9
- *Trace bus (B lines)* on page 2-9.

## Trace memory (M lines)

M lines indicate:

- memory accesses, for cores without on-chip memory
- on-chip memory accesses, for cores with on-chip memory.

They have the following format for general memory accesses:

M<type><rw><size>[0][L][S] <address> <data>

where:

<type>	indicates the cycle type:
S	sequential
N	nonsequential.
<rw>	indicates either a read or a write operation:
R	read
W	write.
<size>	indicates the size of the memory access:
4	word (32 bits)
2	halfword (16 bits)
1	byte (8 bits).
0	indicates an opcode fetch (instruction fetch).
L	indicates a locked access (SWP instruction).
S	indicates a speculative instruction fetch.
<address>	gives the address in hexadecimal format, for example 00008008.
<data>	can show one of the following:
value	gives the read/written value, for example EB00000C
(wait)	indicates <b>nWAIT</b> was LOW to insert a wait state
(abort)	indicates <b>ABORT</b> was HIGH to abort the access.

Trace memory lines can also have any of the following formats:

MI	for idle cycles
MC	for coprocessor cycles
MIO	for idle cycles on the instruction bus of Harvard architecture processors such as ARM9TDMI™.

## Trace instructions (I lines)

The format of the trace instruction (I) lines is as follows:

```
[ IT | IS ] <instr_addr> <opcode> [<disassembly>]
```

For example:

```
IT 00008044 e04ec00f SUB      r12,r14,pc
```

where:

IT	indicates that the instruction was taken.
IS	indicates that the instruction was skipped (almost all ARM instructions are conditional).
<instr_addr>	shows the address of the instruction in hexadecimal format, for example 00008044.
<opcode>	gives the opcode in hexadecimal format, for example e04ec00f.
<disassembly>	gives the disassembly (uppercase if the instruction is taken), for example, SUB r12,r14,pc. This is optional and is enabled by setting Disassemble=True in peripherals.ami.

Branches with link in Thumb code appear as two entries, with the first marked:

1st instr of BL pair.

## Trace events (E lines)

The format of the event (E) lines is as follows:

```
E <word1> <word2> <event_number>
```

For example:

```
E 00000048 00000000 10005
```

where:

<word1>	gives the first of a pair of words, such as the pc value.
<word2>	gives the second of a pair of words, such as the aborting address.
<event_number>	gives an event number, for example 0x10005. This is MMU Event_ITLBWalk. Events are described in <i>Events</i> on page 4-29.

### Trace registers (R lines)

The format of the event (R) lines is as follows:

R <register>=<newvalue>[,<anotherregister>=<newvalue>[...]]

For example:

R r14=20000060, cpsr=200000d3

where:

<register>            is a register that has a new value as a result of the current instruction

<newvalue>           is the new contents of <register>.

### Trace bus (B lines)

The format of bus (B) lines is the same as the format of M lines. B lines indicate off-chip memory accesses.

### 2.3.3 Configuring Tracer

Tracer has its own section in the ARMulator peripherals configuration file (peripherals.am):

```
{ Default_Tracer=Tracer
;; Output options - can be plaintext to file, binary to file or to RDI log
;; window. (Checked in the order RDILog, File, BinFile.)
RDILog=False
File=armul.trc
BinFile=armul.trc
;; Tracer options - what to trace
TraceInstructions=True
TraceRegisters=False
OpcodeFetch=True
;;Normally True is useful, but sometimes it's too expensive.
TraceMemory=True
;TraceMemory=False
TraceIdle=True
TraceNonAccounted=False
TraceEvents=False
;;If there is a non-core bus, do we trace it (as well).
TraceBus=True
;; Flags - disassemble instructions; start up with tracing enabled;
Disassemble=True
TraceEIS=False
StartOn=False
}
```

where:

RDILog	instructs Tracer to output to the RDI log window (in AXD) or the console (under armsd).
File	defines the file where the trace information is written. Alternatively, you can use BinFile to store data in a binary format.

The other options control what is being traced:

TraceInstructions	traces instructions.
TraceRegisters	traces registers.
OpcodeFetch	traces instruction fetch memory accesses.
TraceMemory	traces memory accesses.
TraceIdle	traces idle cycles.



TraceNonAccounted	traces unaccounted RDI accesses to memory. That is, those accesses made by the debugger.
TraceEvents	traces events. For more information, see <i>Tracing events</i> below.
TraceBus	may be: TRUE      Bus (off-chip accesses traced) FALSE     Core (off-chip accesses not traced).
Disassemble	disassembles instructions. Simulation is much slower if you enable disassembly.
TraceEIS	if set TRUE, changes output to a format compatible with other simulators. This allows tools to compare traces.
StartOn	instructs ARMulator to trace as soon as execution begins.

### Other tracing controls

You can also control tracing using:

Range= <i>low address, high address</i>	tracing is carried out only within the specified address range.
Sample= <i>n</i>	only every <i>n</i> th trace entry is sent to the trace file.

### Tracing events

When tracing events, you can select the events to be traced using:

EventMask= <i>mask, value</i>	only those events whose number when masked (bitwise-AND) with <i>mask</i> equals <i>value</i> are traced.
Event= <i>number</i>	only <i>number</i> is traced. (This is equivalent to EventMask=0xFFFFFFFF, <i>number</i> .)

For example, the following traces only MMU/cache events:

```
EventMask=0xFFFF0000,0x00010000
```

See *Events* on page 4-29 for more information.

## 2.4 Profiler

Profiler is controlled by the debugger. For details see *AXD and armsd Debuggers Guide*.

In addition to profiling program execution time, Profiler allows you to use the profiling mechanism to profile events, such as cache misses.

When you turn profiling on from the debugger, you specify a number, *n*, to control the frequency of profiling. See *Configuring Profiler* on page 2-13 for details.

Profiler can profile both C and assembler language functions. To profile assembler language functions you must mark the functions with `FUNCTION` and `ENDFUNC` directives. See *ADS Assembler Guide* for details.

## 2.4.1 Configuring Profiler

Profiler has its own section in `peripherals.amr`, the ARMulator peripherals configuration file:

```
{ Default_Profiler=Profiler
;; For example - to profile the PC value when cache misses happen, set:
;Type=Event
;Event=0x00010001
;EventWord=pc

;;Alternatives for Type are
;; Event, Cycle, Microsecond.
;;If type is Event then alternatives for EventWord are
;; Word1,Word2,PC.
}
```

Every line in this section is a comment, so the ARMulator will perform its default profiling. The default is to take profiling samples at intervals of 100 microseconds. Refer to *AXD and armsd Debuggers Guide* for further information.

If this section is uncommented, data cache misses are profiled. See *Events* on page 4-29 for more information.

The `Type` entry controls how the profiling interval is interpreted:

<code>Type=Microsecond</code>	instructs Profiler to take samples every <i>n</i> microseconds. This is the default.
<code>Type=Cycle</code>	instructs Profiler to take samples every <i>n</i> instructions, and record the number of memory cycles since the last sample.
<code>Type=Event</code>	instructs Profiler to profiles every relevant events, see <i>Events</i> on page 4-29. <i>n</i> is ignored.

`EventMask=mask, value` is also allowed (see *Tracer* on page 2-5).

## 2.5 ARMulator cycle types

In addition to simulating instruction execution on ARM cores, ARMulator counts bus and processor cycles. You can access these counts as `$statistics` from your debugger. This section describes the meaning of the various types of cycles counted. It contains the following sections:

- *Uncached von Neumann cores* on page 2-15
- *Uncached Harvard cores* on page 2-16
- *Cached cores with MMUs or PUs and AMBA ASB interfaces* on page 2-16
- *Cached cores with MMUs or PUs and AMBA AHB interfaces* on page 2-17
- *Internal cycle types for cached cores* on page 2-17
- *strongARM1* on page 2-18
- *Core-specific verbose statistics* on page 2-18.

## 2.5.1 Uncached von Neumann cores

Table 2-1 shows the meanings of cycle types for uncached von Neumann cores. ARM7TDMI, for example, is an uncached von Neumann core.

**Table 2-1 Cycle type meanings for uncached von Neumann cores**

Cycle type	SEQ signal	nMREQ signal	Meaning
S_Cycles	1	1	Sequential cycles. See <i>Sequential cycles</i> for details.
N_Cycles	0	1	Nonsequential cycles. The CPU requests a transfer to or from an address unrelated to the address used in the immediately preceding cycle.
I_Cycles	1	0	Internal cycles. The CPU does not require a transfer because it is performing an internal function.
C_Cycles	0	0	Coprocessor cycles.
Total	-	-	The sum of S_Cycles, N_Cycles, I_Cycles, C_Cycles, and Waits.
IS	-	-	Merged I-S cycle. See <i>Merged I-S cycles</i> for details.

### Sequential cycles

The CPU requests transfer to or from:

- the same address as the address accessed in the immediately preceding cycle
- an address that is one word after the address accessed in the immediately preceding cycle
- for Thumb instruction fetches only, an address that is one half-word after the address accessed in the immediately preceding cycle.

### Merged I-S cycles

A memory controller can start speculatively decoding an address during an I-Cycle. If the I\_Cycle is followed by an S\_Cycle, the memory controller can be ready to issue it earlier than otherwise. The timing of this cycle depends on the memory controller implementation.

2.5.2     Uncached Harvard cores

Table 2-2 shows the meanings of cycle types for uncached Harvard cores. ARM9TDMI, for example, is an uncached Harvard core.

Table 2-2 Cycle type meanings for uncached Harvard cores

Cycle types	Instruction bus	Data bus	Meaning
Core cycles	-	-	The total number of ticks of the core clock. This includes pipeline stalls due to interlocks and instructions that take more than one cycle.
ID_Cycles	Active	Active	-
I_Cycles	Active	Idle	-
Idle Cycles	Idle	Idle	-
D_Cycles	Idle	Active	-
Total	-	-	The sum of core cycles, ID_Cycles, I_Cycles, Idle_Cycles, D_Cycles, and Waits.

2.5.3     Cached cores with MMUs or PUs and AMBA ASB interfaces

Table 2-3 shows the meanings of the bus cycle types for cached cores with AMBA ASB interfaces. For additional cycle types for these cores, see *Internal cycle types for cached cores* on page 2-17.

ARM920T, for example, is a cached core with an MMU. ARM940T is an example of a cached core with a PU.

Table 2-3 Cycle type meanings for cached cores with AMBA ASB interfaces

Cycle types	Meaning
A_Cycles	An address is published speculatively. No data is transferred. Listed as I_Cycles in \$statistics.
S_Cycles	Sequential data is transferred from the current address.

There are no N\_Cycles for these cores. Nonsequential accesses use an A\_Cycle followed by an S\_Cycle. This is the same as a merged I-S cycle.

## 2.5.4 Cached cores with MMUs or PUs and AMBA AHB interfaces

Table 2-4 shows the types of transfer that can occur on the *Advanced High-speed Bus* (AHB). ARM946E-S, for example, is a cached core with an AHB interface. For additional cycle types for these cores, see *Internal cycle types for cached cores*.

**Table 2-4 Cycle types on AMBA AHB interfaces**

Cycle types	Meaning
IDLE	The bus master does not want to use the bus. Slaves must respond with a zero wait state <b>OKAY</b> response on <b>HRESP</b> .
BUSY	The bus master is in the middle of a burst, but cannot proceed to the next sequential access. Slaves must respond with a zero wait state <b>OKAY</b> response on <b>HRESP</b> .
NON-SEQ	The start of a burst or single access. The address is unrelated to the address of the previous access.
SEQ	Continuing with a burst. The address is equal to the previous address plus the data size.

## 2.5.5 Internal cycle types for cached cores

Table 2-5 shows the meaning of internal cycle types for cached cores.

**Table 2-5 Internal cycle types for cached cores**

Cycle types	Meaning
F_Cycles	Fast clock ( <b>FLCK</b> ) cycles. These are internal core cycles accessing the cache. F_Cycles is not incremented for uncached accesses because the core clock switches to the bus clock.
Core Cycles	Core cycles are clock ticks to the core. Core Cycles are incremented for each tick, whether the core is running <b>FCLK</b> (cache accesses) or bus clock ( <b>BCLK</b> , non-cache accesses).
True Idle Cycles	Idle cycles that are not part of a merged I-S cycle.

### ———— Note ————

If you want to count execution time, use external bus cycle counts (see *Cached cores with MMUs or PUs and AMBA ASB interfaces* on page 2-16 or *Cached cores with MMUs or PUs and AMBA AHB interfaces*). You cannot use F\_Cycles to count execution time, because F\_Cycles does not increment for uncached accesses.

2.5.6 strongARM1

Table 2-6 shows the meaning of cycle types reported for strongARM1.

Table 2-6 strongARM specific cycle types

Cycle types	Meaning
Core_Idle	No instruction fetched from instruction cache. No data fetched from data cache.
Core_IOnly	Instruction fetched from instruction cache. No data fetched from data cache.
Core_DOnly	No instruction fetched from instruction cache. Data fetched from data cache.
Core_ID	Instruction fetched from instruction cache. Data fetched from data cache.

2.5.7 Core-specific verbose statistics

There is a line in the default.ami file:

Counters=False

You can change this to read:

Counters=True

If you do this, additional statistics, such as cache hits and cache misses, are counted by ARMulator and appear in \$statistics. These statistics are core-specific.



## 2.6 Pagetable module

This section contains the following subsections:

- *Overview of the pagetable module*
- *Controlling the MMU or PU and cache* on page 2-20
- *Controlling registers 2 and 3* on page 2-20
- *Memory regions* on page 2-21
- *Pagetable module and memory management units* on page 2-23
- *Pagetable module and protection units* on page 2-24.

### 2.6.1 Overview of the pagetable module

The pagetable module enables you to run code on a model of a system with a *Memory Management Unit* (MMU) or a *Protection Unit* (PU), without having to write initialization code for the MMU or PU.

---

**Note**

---

This module allows you to debug code, or perform approximate benchmarking. For a real system, you must write initialization code to set up the MMU or PU. You can debug your initialization code on the ARMulator by disabling the pagetable module.

---

On models of ARM architecture v4 and v5 processors with an MMU, the pagetable module sets up pagetables and initializes the MMU. On processors with a PU, the pagetable module sets up the PU. To control whether to include the pagetable model, find the `Pagetales` tag in the ARMulator configuration file, `default.ami`, and alter it as appropriate:

```
{Pagetales=Default_Pagetales
}
```

or

```
{ Pagetales=No_Pagetales
}
```

The `Pagetales` section in `peripherals.ami` controls the contents of the pagetables, and the configuration of the caches and MMU or PU. To locate the `Pagetales` section, find this line:

```
{Default_Pagetales=Pagetales
```

For full details of the flags, control register and pagetables described in this section, see *ARM Architecture Reference Manual*, or the technical reference manual for the processor you are simulating.

## 2.6.2 Controlling the MMU or PU and cache

The first set of flags enables or disables features of the caches and MMU or PU:

```
MMU=Yes
AlignFaults=No
Cache=Yes
WriteBuffer=Yes
Prog32=Yes
Data32=Yes
LateAbort=Yes
BigEnd=No
BranchPredict=Yes
ICache=Yes
HighExceptionVectors=No
FastBus=No
```

Each flag corresponds to a bit in the system control register, c1 of CP15.

Some flags only apply to certain processors. For example:

- BranchPredict only applies to the ARM810™
- ICache applies to SA™-110 and ARM940T™ processors, but not ARM720 for example.

These flags are ignored by other processor models.

The FastBus flag is used by some cores such as ARM940T. Refer the technical reference manual for your core. If your system uses FastBus Mode, set FastBus=Yes for benchmarking. If set FastBus=No, ARMulator assumes that the memory clock is slower than the core clock by a factor of MCFG. ARMulator does not model Asynchronous mode.

The MMU flag is used to enable the PU in processors with a PU.

## 2.6.3 Controlling registers 2 and 3

The following options apply only to processors with an MMU:

```
PageTableBase=0xA0000000
DAC=0x00000001
```

They control:

- the translation table base register (system control register 2)
- the domain access control register (system control register 3).

You must align the address in the translation table base register to a 16KB boundary.

## 2.6.4 Memory regions

The rest of the Pagetables configuration section defines a set of memory regions. Each region has its own set of properties.

By default, `peripherals.ami` contains a description of a two regions:

```
{ Region[0]
VirtualBase=0
PhysicalBase=0
Size=4GB
Cacheable=No
Bufferable=No
Updateable=Yes
Domain=0
AccessPermissions=3
Translate=Yes
}

{ Region[1]
VirtualBase=0
PhysicalBase=0
Size=128Mb
Cacheable=Yes
Bufferable=Yes
Updateable=Yes
Domain=0
AccessPermissions=3
Translate=Yes
}
```

You can add more regions following the same general form:

Region[ <i>n</i> ]	names the regions, starting with Region[0]. <i>n</i> is an integer.
VirtualBase	applies only to a processor with an MMU. It gives the address of the base of the region in the virtual address space of the processor. This address must be aligned to a 1MB boundary. It is mapped to PhysicalBase by the MMU.
PhysicalBase	gives the physical address of the base of the region. On a processor with an MMU, this address must be aligned to a 1MB boundary. On a processor with a PU it must be aligned to a boundary that is a multiple of the size of the region.
Size	specifies the size of this region. On a processor with an MMU Size must be a whole number of megabytes. On a processor with a PU, Size must be 4KB or a power-of-two multiple of 4KB.

Cacheable	specifies whether the region is to be marked as cacheable. If it is, reads from the region will be cached.
Bufferable	specifies whether the region is to be marked as bufferable. If it is, writes to the region will use the write buffer.
Updateable	applies only to the ARM610™ processor. It controls the U bit in the translation table entry.
Domain	applies only to processors with an MMU. It specifies the domain field of the table entry.
AccessPermissions	specifies the access controls to the region. Refer to the processor technical reference manual for further information.
Translate	controls whether accesses to this region cause translation faults. Setting Translate=No for a region causes an abort to occur whenever the processor reads from or writes to that region.

You must ensure that you do not define more regions than your target hardware supports. At least one region must be defined.

## 2.6.5 Pagetable module and memory management units

Processors such as ARM720T™ and ARM920T™ have an MMU.

An MMU uses a set of page tables, stored in memory, to define memory regions. On reset, the pagetable module writes out a top-level page table to the address specified in the translation table base register. The table corresponds to the regions you define in the Pagetables section of peripherals.ami.

For example, the default configuration details, given in *Memory regions* on page 2-21, define the following page table:

- The entire address space, 4GB, is defined as a single region. This region is not cacheable or bufferable. Virtual addresses are mapped directly to the same physical addresses over the whole address space.
- The first 128MB of the address space is defined as a second region overlapping the first. This region is cacheable and bufferable. Virtual addresses are mapped directly to physical addresses.

They also set up the control registers as follows:

- The translation table base register, register 2, is initialized to point to this page table in memory, at 0xA0000000.
- The domain access control register, register 3, is initialized with value 0x00000001. This sets the access to the region as *client*.
- The M, C and W bits of the control register, register 1, are configured to enable the MMU, cache, and write buffer. If the processor has separate instruction and data caches, the I bit configures the instruction cache enabled.

## 2.6.6 Pagetable module and protection units

Processors such as ARM740T™ and ARM940T™ have a PU.

A PU uses a set of protection regions. The base and size of each protection region is stored in registers in the PU. On reset, the page table module initializes the PU.

For example, the default configuration details given above define a single region, region 0. This region is marked as read/write, cacheable, and bufferable. It occupies the whole address range, 0 to 4GB.

### ARM740T PU

For an ARM740T, the PU is initialized as follows:

- The P, C, and W bits are set in the configuration register, register 1, to enable the protection unit, the cache and the write buffer.
- The cacheable register, register 2, is initialized to 1, marking region 0 as cacheable.
- The write buffer control register, register 3, is initialized to 1, marking region 0 as bufferable.
- The protection register, register 5, is initialized to 3, marking region 0 as read/write access. This is configured in the AccessPermissions line.
- The protection region base and size register for region 0 is initialized to 0x3F, marking the size of region 0 as 4GB and marking the region as enabled. The protection region base and size register for region 0 is part of register 6. Register 6 is actually a set of eight registers, each being the protection region base and size register for one region. See the technical reference manual for the processor for further details.
- The protection region base and size register for region 1 is initialized to set the size of region 0 as 128MB and enabled.

## ARM940T PU

For an ARM940T, the PU is initialized as follows:

- The P, D, W, and I bits are set in the configuration register, register 1, to enable the PU, the write buffer, the data cache and the instruction cache.
- Both the cacheable registers, register 2, are initialized to 1, marking region 0 as cacheable for the I and D caches. This is displayed in the debugger as 0x0101, where:
  - the low byte (bits 0..7) represent the data cache cacheable register
  - the high byte (bits 8..15) represent the instruction cache cacheable register.
- The write buffer control register, register 3, is initialized to 1, marking region 0 as bufferable. This applies only to the data cache. The instruction cache is read only.
- Both the protection registers, register 5, are initialized to 3, marking region 0 as allowing full access for both instruction and data caches. This is displayed in the debugger as 0x00030003, where:
  - the low halfword (bits 0..15) represent the data cache protection register
  - the high halfword (bits 16..31) represent the instruction cache protection register.

The first register value shown is for region 0, the second for region 1 and so on.

- The protection region base and size register for regions 0 and 1 are initialized to mark the sizes of the regions and mark them as enabled. The protection region base and size registers for all regions are part of register 6. Register 6 is really a set of sixteen registers, each being the protection region base and size register for one region. See the data sheet for the processor for further details.
- Register 7 is a control register. Reading from it is unpredictable. At startup the debugger shows a value of zero. It is not written to by the page table module.
- The programming lockdown registers, register 9, are both initialized to zero. The first register value shown in the debugger is for data lockdown control, the second is for instruction lockdown control.
- The test and debug register, register 15, is initialized to zero. Only bits 2 and 3 have any effect in ARMulator. These control whether the cache replacement algorithm is random or round-robin.

## 2.7 Default memory model

The default memory model, flatmem, is a model of a zero-wait state memory system. The simulated memory size is not fixed. Host memory is allocated in chunks of 64KB each time a new region of memory is accessed. The memory size is limited by the host computer, but in theory all 4GB of the address space is available. The default memory model does not generate aborts.

The default memory model is used if you do not specify a mapfile in AXD.

armsd looks in the current directory for a file called armsd.map. If it cannot find one, the default memory model is used.

The default memory model routes memory accesses to memory-mapped peripheral models as appropriate. Routing is based on configuration details you provide in peripherals.ami, or another .ami file.



## 2.8 Memory modelling with mapfiles

This section contains the following subsections:

- *Overview of memory modelling with mapfiles*
- *Clock frequency*
- *Selecting the mapfile memory model on page 2-28*
- *How the mapfile memory model calculates wait states on page 2-28*
- *Configuring the map memory model on page 2-29.*

### 2.8.1 Overview of memory modelling with mapfiles

mapfile is a memory model which you can configure yourself. You can specify the size, access width, access type and access speeds of individual memory blocks in the memory system in a memory map file (see *Map files* on page 4-59).

ARMulator simulates each memory access as it occurs. It counts wait states according to the type of memory access.

The debugger internal variables \$memstats and \$statistics give details of accesses of each cycle type, regions of memory accessed and time spent accessing each region (see *AXD and armsd Debuggers Guide* for information on retrieving details of debugger internal variables).

### 2.8.2 Clock frequency

You can configure the clock frequency used by mapfile from the debugger. See *AXD and armsd Debuggers Guide* for details.

The clock frequency is used to determine the number of wait states to be added to each memory access, as well as to calculate time from number of cycles.

If you do not specify a clock speed, a value of 20MHz is used. If you specify a number without units, the units are Hz. You can specify Hz, kHz, or MHz.

### 2.8.3 Selecting the mapfile memory model

Under armsd, the map memory model inserts itself automatically, if loaded, as the memory model to use whenever an armsd.map file exists in the directory where armsd is started.

Under AXD, the map memory model is automatically inserted whenever a memory map file is specified. Specify map files using the **Memory Maps** tab of the ARMulator configuration dialog.

### 2.8.4 How the mapfile memory model calculates wait states

The memory map file specifies access times in nanoseconds for nonsequential/sequential reads/writes to various regions of memory. By inserting wait states, the map memory model ensures that every access from the ARM processor takes at least that long.

The number of wait states inserted is the least number required to take the total access time over the number of nanoseconds specified in the memory map file. Consider this when designing your system.

For example, with a clock speed of 33MHz (a period of 30ns), an access specified to take 70ns in a memory map file results in two wait states being inserted, to lengthen the access to 90ns.

If the access time is 60ns (only 14% faster) the model inserts only one wait state (33% quicker).

A mismatch between processor clock-speed and memory map file can sometimes lead to faster processor speeds having worse performance. For example, a 100MHz processor (10ns period) takes five wait states to access 60ns memory (a total access time of 60ns). At 110MHz, the map memory model must insert six wait states (a total access time of 63ns). So the 100MHz-processor system is faster than the 110MHz processor. (This does not apply to cached processors, where the 110MHz processor would be faster.)

---

#### **Note**

For accurate simulation of the real hardware, access times specified in the memory map file must include propagation delays and memory controller decode time as well as the access time of the memory devices. For example, for 70ns RAM, if there is a 10ns propagation delay, configure the map file as 80ns.

---

## 2.8.5 Configuring the map memory model

You can configure the map memory model to model several different types of memory controller, by editing its entry in the `peripherals.ami` file:

```
{ Default_Mapfile=Mapfile
  AMBABusCounts=False
  ;SpotISCycles=True|False
  SpotISCycles=True
  ;ISTiming=Late|Early|Speculative
  ISTiming=Late
}
```

### Counting AMBA™ decode cycles

You can configure the model to insert an extra decode cycle for every nonsequential access from the processor. This models the decode cycle seen on some AMBA bus systems. Enable this by setting `AMBABusCounts=True` in `peripherals.ami`.

### Merged I-S cycles

All ARM processors, particularly cached processors, can perform a nonsequential access as a pair of idle and sequential cycles, known as *merged I-S cycles*. By default, the model treats these cycles as a nonsequential access, inserting wait states on the S-cycle to lengthen it for the nonsequential access.

You can disable this by setting `SpotISCycles=False` in `peripherals.ami`. However, this is likely to result in exaggerated performance figures, particularly when modeling cached ARM processors.

The model can simulate merged I-S cycles using one of three strategies:

**Speculative** This models a system where the memory controller hardware speculatively decodes all addresses on idle cycles. The controller can use both the I- and S-cycles to perform the access. This results in one fewer wait state.

**Early** This starts the decode when the ARM declares that the next cycle is going to be an S-cycle, that is, half-way through the I-cycle. This can sometimes result in one fewer wait states. (Whether or not there are fewer wait states depends on the cycle time and the nonsequential access time for that region of memory.)

This is the default setting. You can change this by setting `ISTiming=Spec` or `ISTiming=Late` in `peripherals.ami`.

**Late** This does not start the decode until the S-cycle. In effect all S-cycles that follow an I-cycle are treated as if they are N-cycles.

See *ARMulator cycle types* on page 2-14 for details of merged I-S cycles.

## 2.9 Semihosting

Semihosting provides code running on an ARM target use of facilities on a host computer that is running an ARM debugger. Examples of such facilities include the keyboard input, screen output, and disk I/O.

See Chapter 5 *Semihosting* for further details.

### 2.9.1 Semihosting configuration

The semihosting SWI handler configuration is controlled by a section in `peripherals.ami`. It has the following items:

```
{Default_Semihost=Semihost
; Demon is only needed for validation.
DEMON=False
ANGEL=TRUE
AngelSWIARM=0x123456
AngelSWIThumb=0xab
; And the default memory map
HeapBase=0x00000000
HeapLimit=0x07000000
StackBase=0x08000000
StackLimit=0x07000000
}
```

## 2.10 Peripheral models

ARMulator includes several peripheral models. This section gives basic user information about them.

This section contains the following subsections:

- *Configuring ARMulator to use the peripheral models*
- *Interrupt controller* on page 2-33
- *Timer* on page 2-34
- *Watchdog* on page 2-35
- *Stack tracker* on page 2-36
- *Tube* on page 2-36.

### 2.10.1 Configuring ARMulator to use the peripheral models

Enable or disable each peripheral model by changing the relevant entry in your copy of the `default.ami` file, for example:

```
{ WatchDog=No_watchdog
}
```

can be changed to:

```
{ Watchdog=Default_WatchDog
}
```

Other peripheral models are controlled in the same way, using the `No_` and `Default_` prefixes to the peripheral names.

### 2.10.2 Configuring details of the peripherals

Configuration details for the peripheral models are in `peripherals.ami`. See *Configuring ARMulator* on page 2-4 for information about how to alter `.ami` files.

### 2.10.3 Interrupt controller

The interrupt controller is an implementation of the reference interrupt controller (see *Interrupt controller* on page 4-75).

The configuration of the interrupt controller model is controlled by a section in `peripherals.ami`. It has the following items:

```
{ Default_Intctrl=Intctrl  
  Range:Base=0x0a000000  
  WAITS=0  
}
```

`Range:Base` specifies the area in memory into which the interrupt controller registers are mapped. For details of the interrupt controller registers, see *Interrupt controller* on page 4-75.

`WAITS` specifies the number of wait states that accessing the interrupt controller imposes on the processor. The maximum is 30.

## 2.10.4 Timer

The timer is an implementation of the reference timer. It provides two counter-timers. For details see *Timer* on page 4-77.

The configuration of the timer model is controlled by a section in `peripherals.ami`. It has the following items:

```
{Default_Timer=Timer
Range:Base=0x0a800000
;Frequency of clock to controller.
CLK=20000000
;; Interrupt controller source bits - 4 and 5 as standard
IntOne=4
IntTwo=5
WAITS=0
}
```

`Range:Base` specifies the area in memory into which the timer registers are mapped. For details of the interrupt controller registers, see *Timer* on page 4-77.

`CLK` is used to specify the clock rate of the peripheral. This is usually the same as the processor clock rate.

`IntOne` specifies the interrupt line connection to the interrupt controller for timer 1 interrupts. `IntTwo` specifies the interrupt line connection to the interrupt controller for timer 2 interrupts.

`WAITS` specifies the number of wait states that accessing the timer imposes on the processor. The maximum is 30.



## 2.10.5 Watchdog

Use Watchdog to prevent a failure in your program locking up your system. If your program fails to access Watchdog before a predetermined time, Watchdog halts ARMulator and returns control to the debugger.

---

### Note

---

This is a generic model of a watchdog timer. It is supplied to help users model their system environment. It does not model any actual hardware supplied by ARM.

---

The Watchdog configuration is controlled by a section in `peripherals.ami`. It has the following items:

```
{Default}_WatchDog=WatchDog
Range:Base=0xb0000000
KeyValue=0x12345678
WatchPeriod=0x80000
IRQPeriod=3000
IntNumber=16
StartOnReset=True
RunAfterBark=True
WAITS=0
}
```

Range:Base specifies the area in memory into which the watchdog registers are mapped.

This is a two-timer watchdog.

If StartOnReset is True, the first timer starts on reset. If StartOnReset is False, the first timer starts only when your program writes the configured key value to the KeyValue register. This is located at the address given in the Range:Base line (0xB0000000).

The first timer generates an **IRQ** after WatchPeriod memory cycles, and starts the second timer. The second timer times out after IRQPeriod memory cycles, if your program has not written the configured key value to the KeyValue register. Configure IRQPeriod to a suitable value to allow your program to react to the **IRQ**.

If RunAfterBark is True, Watchdog halts ARMulator if the second timer times out. You can continue to execute, or debug.

If RunAfterBark is False, Watchdog halts ARMulator and returns control to the debugger.

IntNumber specifies the interrupt line number that Watchdog is attached to.

WAITS specifies the number of wait states that accessing the watchdog imposes on the processor. The maximum is 30.

### 2.10.6 Stack tracker

The stack tracker examines the contents of the stack pointer (r13) after each instruction. It keeps a record of the lowest value and from this it can work out the maximum size of the stack. ARMulator runs more slowly with stack tracking enabled.

The StackUse model continually monitors the stack pointer and reports the amount of stack used in \$statistics. It must be configured with the location of the stack.

The stack tracker is disabled by default. To enable the stack tracker, edit your copy of `default.ami`:

1. Find the line:  

```
{ StackUse=No_StackUse
```
2. Change it to:  

```
{ StackUse=Default_StackUse
```

Before initialization the stack pointer can contain values outside the stack limits. You must configure the stack limits so that the stack tracker can ignore these pre-initialization values. This configuration is in `peripherals.ami`:

```
{ Default_StackUse=StackUse
StackBase=0x80000000
StackLimit=0x70000000
}
```

StackBase is the address of the top of the stack. StackLimit is a lower limit for the stack. Changing these values does not reposition the stack in memory. To reposition the stack, you must reconfigure the debug monitor model.

### 2.10.7 Tube

The tube is a memory-mapped register. If you write a printable character to it, the character appears on the console. It allows you to check that writes are taking place to a specified location in memory.

You can change the address at which the Tube is mapped. This is controlled by an entry in `peripherals.ami`:

```
{Default_Tube=Tube
Range:Base=0x0d800020
}
```

This is the default address.

# Chapter 3

## Writing ARMulator models

This chapter is intended to assist you in writing your own models to add to ARMulator. It contains the following sections:

- *The ARMulator extension kit* on page 3-2
- *Writing a new peripheral model* on page 3-5
- *Building a new model* on page 3-7
- *Configuring ARMulator to use a new model* on page 3-8
- *Configuring ARMulator to disable a model* on page 3-10.

## 3.1 The ARMulator extension kit

You can add extra models to ARMulator without altering the existing models. Each model is self-contained, and communicates with ARMulator through defined interfaces. The definition of these interfaces is in Chapter 4 *ARMulator Reference*.

### 3.1.1 Location of files

The ARMulator extension kit contains the source code of some models. You can make copies of these models, and modify the copies. The ARMulator extension kit is only installed if you install a full or custom installation of ADS.

Depending on your system, the source code of the models for you to copy is in one of:

- `install_directory\ARMulate\ARMulext`
- `install_directory/solaris/Source/armulext`
- `install_directory/linux/Source/armulext`
- `install_directory/hpux/Source/armulext`

There are also header files in:

- `install_directory\ARMulate\ARMulif`
- `install_directory/solaris/Source/armulif`
- `install_directory/linux/Source/armulif`
- `install_directory/hpux/Source/armulif`

Makefiles are supplied in:

- `install_directory\ARMulate\ARMulext\model\intelrel`
- `install_directory/solaris/Source/armulext/model/gccsolrs`
- `install_directory/linux/Source/armulext/model/linux86`
- `install_directory/hpux/Source/armulext/model/cchppa`

Use these files as examples to help you write your own models. To help you choose suitable models to examine, this chapter includes a list of them with brief descriptions of what they do (see *Supplied models* on page 3-3).

### 3.1.2 Supplied models

ARMulator is supplied with source code for the following groups of models:

- *Basic models*
- *Peripheral models* on page 3-4

#### Basic models

tracer.c	The tracer module can trace instruction execution and events from within ARMulator (see <i>Tracer</i> on page 4-57). You can link your own tracing code onto the tracer module.
profiler.c	The profiler module provides the profiling function (see <i>Profiler</i> on page 2-12). This includes basic instruction sampling and more advanced use, such as profiling cache misses. It does this by providing an <code>UnkRDIInfoHandler</code> that handles the profiling requests from the debugger (see <i>Unknown RDI information handler</i> on page 4-35).
pagetab.c	On reset, this module sets up cache, PU or MMU and associated pagetables inside ARMulator (see <i>Pagetable module</i> on page 2-19).
stackuse.c	If enabled this model tracks the stack size. Stack usage is reported in the ARMulator memory statistics. You can set the stack upper and lower bounds in the <code>peripherals.ami</code> file (see <i>Stack tracker</i> on page 2-36).
nothing.c	This model does nothing. You can use this in the <code>peripherals.ami</code> file to disable models (see <i>Configuring ARMulator to disable a model</i> on page 3-10).
semihost.c	This model provides the semihosting SWIs described in Chapter 5 <i>Semihosting</i> .
dcc.c	This is a model of a <i>Debug Communications Channel</i> (DCC).
mapfile.c	This model allows you to specify the characteristics of a memory system. See <i>Map files</i> on page 4-59 for further information.
flatmem.c	<code>flatmem</code> models a zero-wait state memory system. See <i>Default memory model</i> on page 2-26 for further information.

## Peripheral models

<code>intc.c</code>	See <i>Interrupt controller</i> on page 2-33. <code>intc</code> is a model of the interrupt controller peripheral described in the <i>Reference Peripherals Specification</i> (RPS).
<code>timer.c</code>	See <i>Timer</i> on page 2-34. <code>timer</code> is a model of the RPS timer peripheral. Two timers are provided. <code>timer</code> must be used in conjunction with an interrupt controller, but not necessarily <code>intc</code> .
<code>millisec.c</code>	A simple millisecond timer.
<code>watchdog.c</code>	Watchdog. See <i>Watchdog</i> on page 2-35. <code>watchdog</code> is a generic watchdog model. It does not model any specific watchdog hardware, but provides generic watchdog functions.
<code>tube.c</code>	Tube. See <i>Tube</i> on page 2-36. <code>tube</code> is a simple debugging aid. It allows you to check that writes are taking place to a specified location in memory.

## 3.2 Writing a new peripheral model

This section contains the following subsections:

- *Using a sample model as a template*
- *Return values*
- *Initialization, finalization, and state macros* on page 3-6
- *Registering your model* on page 3-6.

### 3.2.1 Using a sample model as a template

To write a new model, the best procedure is to copy one of the supplied models and then edit the copy. To do this:

1. Select which model is closest to the model you want to write. This might be, for example, `Timer`.
2. Copy the source file, in this case `timer.c`, with a new name such as `mymodel.c`.
3. Copy the make subdirectory, in this case `timer.b`, with a corresponding new name, in this case `mymodel.b`.
4. Find the `Makefile` for your model (see *Location of files* on page 3-2).  
Load `Makefile` into a text editor and change all instances of `timer` to `mymodel`.

You can now edit `MyModel`.

### 3.2.2 Return values

A model must return one of the following states for memory accesses:

<code>PERIP_OK</code>	If the model is able to service the request.
<code>PERIP_BUSY</code>	If a memory access requires wait-states. A model must not return this state to a debugger access.
<code>PERIP_DABORT</code>	If a peripheral asserts the <b>DABORT</b> signal on the bus.
<code>PERIP_NODECODE</code>	If the model has been called with an address which belongs to it, but which has no meaning to it. The memory model handles the call as a memory access.

### 3.2.3 Initialization, finalization, and state macros

To help you to write new ARMulator models, the following six macros are provided in `minperip.h`:

- `BEGIN_INIT()`
- `END_INIT()`
- `BEGIN_EXIT()`
- `END_EXIT()`
- `BEGIN_STATE_DECL()`
- `END_STATE_DECL()`.

Use the following to define an initialization function for your model:

```
BEGIN_INIT(your_model)
{
    /*
     * (your initialization code here)
     */
}
END_INIT(your_model)
```

Use the following to define a finalization function for your model:

```
BEGIN_EXIT(your_model)
{
    /*
     * (your finalization code here)
     */
}
END_EXIT(your_model)
```

The `BEGIN_INIT()` macro defines a structure to hold any private data used by your model, and the `END_EXIT()` macro frees it. Declare the data structure using:

```
BEGIN_STATE_DECL(your_model)
/*
 * (your private data here)
 */
END_STATE_DECL(your_model)
```

### 3.2.4 Registering your model

Your model must register itself by calling `registerPeripFunc()`. This enables ARMulator to call your model with accesses to memory locations that belong to your model. See *ARMul\_BusRegisterPeripFunc* on page 4-41.



### 3.3 Building a new model

To build your new model:

1. Change your current directory to:  
`mymodel.b\targetwhere` *target* is one of:
  - `intelrel`
  - `linux86`
  - `gccsolaris`
  - `cchppa`.
2. Build the model using the make utility installed on your system. This might be one of:
  - `nmake` for Windows
  - `make` for Linux, Solaris or HPUX.
3. Depending on your system:
  - On Windows, `mymodel.dll` appears in:  
`install_directory\ARMulate\armulext\mymodel.b\intelrel`  
 Move `mymodel.dll` to:  
`install_directory\Bin`
  - On Linux or Solaris, `mymodel.so` appears in:  
`install_directory/Source/armulext/mymodel.b/target`  
 Move `mymodel.so` to:  
`install_directory/target/bin`
  - On HPUX, `mymodel.sl` appears in:  
`install_directory/Source/armulext/mymodel.b/cchppa`  
 Move `mymodel.sl` to:  
`install_directory/cchppa/bin`

ARMulator expects to find models in `install_directory\bin` or `install_directory/os/bin`, where *os* is one of:

- `solaris`
- `linux`
- `hpux`.

## 3.4 Configuring ARMulator to use a new model

ARMulator determines which models to use by reading the `.ami` and `.dsc` configuration files. See *ARMulator configuration files* on page 4-63.

Before a new model can be used by ARMulator, you must add a `.dsc` file for your model, and references to it must be added to the configuration files `default.ami` and `peripherals.ami`.

The procedures are described in the following subsections:

- *Adding a .dsc file*
- *Editing default.ami and peripherals.ami* on page 3-9.

### 3.4.1 Adding a .dsc file

Create a file called `MyModel.dsc` and place it in `install_directory\Bin`. It must contain the following:

```
;; ARMulator configuration file type 3
{ Peripherals
  {MyModel
    MODEL_DLLfilename=MyModel
  }
  {
    No_MyModel=Nothing
  }
}
```

where the name of your model is one of:

- `MyModel.dll`
- `MyModel.so`
- `MyModel.sl`

Nothing is a predefined model that does nothing. The `No_MyModel=Nothing` line allows the use of `No_MyModel` in a `.ami` file. This allows a user to configure ARMulator to exclude your model (see *Configuring ARMulator to disable a model* on page 3-10).

You can include other configuration details in your `MyModel.dsc` file if required. See the supplied `.dsc` files in `install_directory\Bin` for examples.

### 3.4.2 Editing default.ami and peripherals.ami

This description assumes that your model was based on Timer:

1. Load the default.ami file into a text editor, and find the following lines:  

```
{Timer=Default_Timer  
}
```
2. Add the reference to your model:  

```
{Timer=Default_Timer  
}  
  
{MyModel=Default_MyModel  
}
```
3. Save your edited default.ami file.
4. Load the peripherals.ami file into a text editor, and find the Timer section:  

```
{ Default_Timer=Timer  
.  
.  
.  
}
```
5. Using this as an example, add a configuration section for your model. Depending on how much your model differs from Timer, it may be easiest to edit a copy of the Timer section.
6. Save your edited peripherals.ami file.

## 3.5 Configuring ARMulator to disable a model

You can disable a model by changing its entry in `peripherals.ami`. For example, to disable the Tube model:

1. Find the following lines in `peripherals.ami`:

```
{Defaultt_Tube=Tube  
Range:Base=0x0d800020  
}
```

2. Change them to read:

```
{Defaultt_Tube=No_Tube  
Range:Base=0x0d800020  
}
```

This uses the `nothing.c` model to override the `tube.c` model. `nothing` ignores any configuration details such as `Range:Base`.

# Chapter 4

## ARMuLator Reference

This chapter gives reference information about ARMuLator. It contains the following sections:

- *ARMuLator models* on page 4-2
- *Communicating with the core* on page 4-3
- *Basic model interface* on page 4-12
- *Coprocessor model interface* on page 4-15
- *Exceptions* on page 4-26
- *Events* on page 4-29
- *Memory access functions* on page 4-38
- *Event scheduling functions* on page 4-40
- *General purpose functions* on page 4-41
- *Accessing the debugger* on page 4-52
- *Tracer* on page 4-57
- *Map files* on page 4-59
- *ARMuLator configuration files* on page 4-63
- *ToolConf* on page 4-68
- *Reference peripherals* on page 4-75.

## 4.1 ARMulator models

ARMulator comprises a collection of models that simulate ARM-based hardware. They enable you to benchmark, develop, and debug software before your hardware is available.

### 4.1.1 Configuring models through ToolConf

ARMulator models are configured through ToolConf. ToolConf is a database of tags and values that ARMulator reads from configuration files (.dsc and .ami files) during initialization (see *ToolConf* on page 4-68).

A number of functions are provided for looking up values from this database. The full set of functions is defined in *install\_directory\ARMulate\clx\toolconf.h*. All the functions take an opaque handle called a *toolconf*.

## 4.2 Communicating with the core

During initialization, all the models receive a pointer to an `mdesc` structure of type `RDI_ModuleDesc *`. They copy this structure into their own state as a field called `coredesc`. This is passed as the first parameter to most *ARMulif* (ARMulator interface) functions. ARMulator exports these functions to enable models to access the ARMulator state through this handle.

The following functions provide read and write access to ARM registers:

- *ARMulif\_GetReg* on page 4-5
- *ARMulif\_SetReg* on page 4-5
- *ARMulif\_GetPC* and *ARMulif\_GetR15* on page 4-6
- *ARMulif\_SetPC* and *ARMulif\_SetR15* on page 4-6
- *ARMulif\_GetCPSR* on page 4-7
- *ARMulif\_SetCPSR* on page 4-7
- *ARMulif\_GetSPSR* on page 4-8
- *ARMulif\_SetSPSR* on page 4-8.

A model must pass a pointer to their `coredesc` structure when calling a function in *ARMulif* that calls the core.

The following functions provide convenient access to specific bits or fields in the CPSR:

- *ARMulif\_ThumbBit* on page 4-9
- *ARMulif\_GetMode* on page 4-9.

The following functions call the read and write methods for a coprocessor:

- *ARMulif\_CPRead* on page 4-10
- *ARMulif\_CPWrite* on page 4-11.

---

### Note

It is not appropriate to access some parts of the state from certain parts of a model. For example, you must not set the contents of an ARM register from a memory access function, because the memory access function can be called during simulation of an instruction. In contrast, it is sometimes necessary to set the contents of ARM registers from a SWI handler function.

---

### 4.2.1 Mode numbers

A number of the following functions take an **unsigned** mode parameter to specify the processor mode. The mode numbers are defined in `armdefs.h`, and are listed here:

- `USER32MODE`
- `FIQ32MODE`
- `IRQ32MODE`
- `SVC32MODE`
- `ABORT32MODE`
- `UNDEF32MODE`
- `SYSTEM32MODE`

In addition, the special value `CURRENTMODE` is defined. This enables `ARMulIf_GetReg()`, for example, to return registers of the current mode.



### 4.2.2 ARMulif\_GetReg

This function reads a register for a specified processor mode.

#### Syntax

```
ARMword ARMulif_GetReg(RDI_ModuleDesc *mdesc, ARMword mode, unsigned reg)
```

where:

<i>mdesc</i>	is the handle for the core.
<i>mode</i>	is the processor mode. Values for mode are defined in <code>armdefs.h</code> (see <i>Mode numbers</i> on page 4-4).
<i>reg</i>	is the register to read. Valid values are 0 to 14 for registers r0 to r14, PC, or CPSR.

#### Return

The function returns the value in the given register for the specified mode.

### 4.2.3 ARMulif\_SetReg

This function writes a register for a specified processor mode.

#### Syntax

```
void ARMulif_SetReg(RDI_ModuleDesc *mdesc, ARMword mode,  
                    unsigned reg, ARMword value)
```

where:

<i>mdesc</i>	is the handle for the core.
<i>mode</i>	is the processor mode. Mode numbers are defined in <code>armdefs.h</code> (see <i>Mode numbers</i> on page 4-4).
<i>reg</i>	is the register to write. Valid values are 0 to 14 for registers r0 to r14, PC, or CPSR.
<i>value</i>	is the value to be written to register <i>reg</i> for the specified processor mode.

#### Usage

You can use this function to write to any of the general purpose registers r0 to r14, the PC, or CPSR.

#### 4.2.4 ARMulif\_GetPC and ARMulif\_GetR15

This function reads the pc. ARMulif\_GetPC and ARMulif\_GetR15 are synonyms.

##### Syntax

```
ARMword ARMulif_GetPC(RDI_ModuleDesc *mdesc)
```

```
ARMword ARMulif_GetR15(RDI_ModuleDesc *mdesc)
```

where:

*mdesc* is the handle for the core.

##### Return

This function returns the value of the pc.

#### 4.2.5 ARMulif\_SetPC and ARMulif\_SetR15

This function writes a value to the pc. ARMulif\_SetPC and ARMulif\_SetR15 are synonyms.

##### Syntax

```
void ARMulif_SetPC(RDI_ModuleDesc *mdesc, ARMword value)
```

```
void ARMulif_SetR15(RDI_ModuleDesc *mdesc, ARMword value)
```

where:

*mdesc* is the handle for the core.

*value* is the value to be written to the pc.

### 4.2.6 ARMulif\_GetCPSR

This function reads the CPSR.

#### Syntax

```
ARMword ARMulif_GetCPSR(RDI_ModuleDesc *mdesc)
```

where:

*mdesc* is the handle for the core.

#### Return

The function returns the value of the CPSR.

### 4.2.7 ARMulif\_SetCPSR

This function writes a value to the CPSR.

#### Syntax

```
void ARMulif_SetCPSR(RDI_ModuleDesc *mdesc, ARMword value)
```

where:

*mdesc* is the handle for the core.

*value* is the value to be written to the CPSR.

### 4.2.8 ARMulif\_GetSPSR

This function returns the current contents of the SPSR for a specified processor mode.

#### Syntax

```
ARMword ARMulif_GetSPSR(RDI_ModuleDesc *mdesc, ARMword mode)
```

where:

*mdesc* is the handle for the core.

*mode* is the processor mode for the SPSR you want to read.

#### User mode

ARMulif\_GetSPSR returns the current contents of the CPSR if *mode* is USER32MODE.

### 4.2.9 ARMulif\_SetSPSR

This function writes a value to the SPSR for a specified processor mode.

#### Syntax

```
void ARMulif_SetSPSR(RDI_ModuleDesc *mdesc, ARMword mode, ARMword value)
```

where:

*mdesc* is the handle for the core.

*mode* is the processor mode for the SPSR you want to write.

*value* is the value to be written to the SPSR for the specified mode.

#### User mode

ARMulif\_SetSPSR does nothing if *mode* is USER32MODE.

#### 4.2.10 ARMulif\_ThumbBit

This function returns 1 if the core is in Thumb state, 0 if the core is in ARM state.

##### Syntax

```
unsigned ARMulif_ThumbBit(RDI_ModuleDesc *mdesc)
```

where:

*mdesc* is the handle for the core.

#### 4.2.11 ARMulif\_GetMode

This function reads the current processor mode.

##### Syntax

```
unsigned ARMulif_GetMode(RDI_ModuleDesc *mdesc)
```

where:

*mdesc* is the handle for the core.

#### 4.2.12 ARMulif\_CPRead

This function calls the read method for a coprocessor.

##### Syntax

```
int ARMulif_CPRead(RDI_ModuleDesc *mdesc, unsigned cpnum,  
                  unsigned reg, ARMword *data)
```

where:

<i>mdesc</i>	is the handle for the core.
<i>cpnum</i>	is the number of the coprocessor.
<i>reg</i>	is the number of the coprocessor register to read from, as indexed by CRn in an LDC or STC instruction.
<i>data</i>	is a pointer for the data read from the coprocessor register. The number of words transferred, and the order of the words, is coprocessor dependent.

##### Return

The function must return:

- ARMul\_DONE, if the register can be read
- ARMul\_CANT, if the register cannot be read.

### 4.2.13 ARMulif\_CPWrite

This function calls the write method for a coprocessor. It also intercepts calls to write the FPE emulated registers.

#### Syntax

```
int ARMulif_CPWrite(RDI_ModuleDesc *mdesc, unsigned cpnum,  
                   unsigned reg, ARMword *data)
```

where:

<i>mdesc</i>	is the handle for the core.
<i>cpnum</i>	is the number of the coprocessor.
<i>reg</i>	is the number of the coprocessor register to read from, as indexed by CRn in an LDC or STC instruction.
<i>data</i>	is a pointer for the data read from the coprocessor register. The number of words transferred, and the order of the words, is coprocessor dependent.

#### Return

The function must return:

- ARMu1\_DONE, if the register can be written
- ARMu1\_CANT, if the register cannot be written.

## 4.3 Basic model interface

This section has the following subsections:

- *Declaration of a private state data structure* on page 4-13
- *Model initialization* on page 4-14
- *Model finalization* on page 4-14.

For each model, you must write an initialization function. For additional functionality, you must register callbacks.

Macros are provided in `minperip.h` for the following abstractions:

- *Declaration of a private state data structure* on page 4-13
- *Model initialization* on page 4-14
- *Model finalization* on page 4-14.

See also *Initialization, finalization, and state macros* on page 3-6.



### 4.3.1 Declaration of a private state data structure

Each model must store its state in a private data structure. Initialization and finalization macros are provided by ARMulif. These macros require the use of certain fields in this data structure.

To declare a state data structure, use the BEGIN\_STATE\_DECL and END\_STATE\_DECL macros as follows:

```
/*
 * Create a YourModelState data structure
 */
BEGIN_STATE_DECL(YourModel)
/*
 * Your private data here
 */
END_STATE_DECL(YourModel)
```

This declares a structure:

```
typedef struct YourModelState
```

This structure contains:

- predefined data fields:
  - toolconf config
  - const struct RDI\_HostosInterface \*hostif
  - RDI\_ModuleDesc coredesc;
  - RDI\_ModuleDesc agentdesc
- the private data you put between the macros.

### 4.3.2 Model initialization

The `BEGIN_INIT()` and `END_INIT()` macros form the start and finish of the initialization function for the model. The initialization function is called:

- during ARMulator initialization
- whenever a new image is downloaded from the debugger.

The following local variables are provided in the initialization function:

- **bool** `coldboot`  
TRUE if ARMulator is initializing, FALSE if a new image is being downloaded from the debugger.
- `YourModelState *state`  
A pointer to the private state data structure. Memory for this is allocated and cleared by the initialization macro, and the predefined data fields are initialized.

In the initialization function, your model must:

- initialize any private data
- install any callbacks.

### 4.3.3 Model finalization

The `BEGIN_EXIT()` and `END_EXIT()` macros form the start and finish of the finalization function for the model. The finalization function is called when ARMulator is closing down.

The following local variable is provided in the finalization function:

`YourModelState *state`

Your model must de-install any callbacks in the finalization function.

The `END_EXIT()` macro frees memory allocated for state.

## 4.4 Coprocessor model interface

The coprocessor model interface is defined in `armul_copro.h`. The basic coprocessor functions are:

- *ARMulif\_InstallCoproprocessorV5* on page 4-16
- *LDC* on page 4-17
- *STC* on page 4-18
- *MRC* on page 4-19
- *MCR* on page 4-20
- *MRC* on page 4-19
- *MCR* on page 4-20
- *MCRR* on page 4-21
- *MRRC* on page 4-22
- *CDP* on page 4-23.

In addition, two functions are provided that enable a debugger to read and write coprocessor registers through the *Remote Debug Interface* (RDI). They are:

- *read* on page 4-24
- *write* on page 4-25.

If a coprocessor does not handle one or more of these functions, it must leave their entries in the `ARMul_CPIInterface` structure unchanged.

#### 4.4.1 ARMulif\_InstallCoproprocessorV5

Use this function to register a coprocessor handler.

This function is prototyped in `armul_copro.h`.

##### Syntax

```
unsigned ARMulif_InstallCoproprocessorV5(RDI_ModuleDesc *mdesc, unsigned number,  
                                         struct ARMul_CoproprocessorV5 *cpv5, void *handle)
```

where:

*mdesc* is the handle for the core.

*number* is the coprocessor number.

*cpv5* is a pointer to the coprocessor interface structure.

*handle* is a pointer to private data to pass to each coprocessor function.

##### Return

This function returns either:

- `ARMulErr_NoError`, if there is no error
- an `ARMul_Error` value.

See `armerrs.h` and `errors.h` for a full list of error codes. The error must be passed through `Hostif_RaiseError()` for formatting (see *Hostif\_RaiseError* on page 4-45).

## 4.4.2 LDC

This function is called when an LDC instruction is recognized for a coprocessor.

### Syntax

```
unsigned LDC(void *handle, int type, ARMword instr, ARMword *data)
```

where:

<i>handle</i>	is the handle from <code>ARMu1if_InstallCoproprocessorV5</code> .										
<i>type</i>	is the type of coprocessor access. This can be one of: <table border="0"> <tr> <td><code>ARMu1_CP_FIRST</code></td><td>indicates that this is the first time the coprocessor model has been called for this instruction.</td></tr> <tr> <td><code>ARMu1_CP_BUSY</code></td><td>indicates that this is a subsequent call, after the first call was busy-waited.</td></tr> <tr> <td><code>ARMu1_CP_INTERRUPT</code></td><td>warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code>.</td></tr> <tr> <td><code>ARMu1_CP_TRANSFER</code></td><td>indicates that the ARM is about to perform the load.</td></tr> <tr> <td><code>ARMu1_CP_DATA</code></td><td>indicates that valid data is included in <i>data</i>.</td></tr> </table>	<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.	<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.	<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .	<code>ARMu1_CP_TRANSFER</code>	indicates that the ARM is about to perform the load.	<code>ARMu1_CP_DATA</code>	indicates that valid data is included in <i>data</i> .
<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.										
<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.										
<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .										
<code>ARMu1_CP_TRANSFER</code>	indicates that the ARM is about to perform the load.										
<code>ARMu1_CP_DATA</code>	indicates that valid data is included in <i>data</i> .										
<i>instr</i>	the current opcode.										
<i>data</i>	is a pointer to the data being loaded to the coprocessor from memory.										

### Return

The function must return one of:

- `ARMu1_CP_INC`, to request more data from the core (only in response to `ARMu1_CP_FIRST`, `ARMu1_CP_BUSY`, or `ARMu1_CP_DATA`)
- `ARMu1_CP_DONE`, to indicate that the coprocessor operation is complete (only in response to `ARMu1_CP_DATA`)
- `ARMu1_CP_BUSY`, to indicate that the coprocessor is busy (only in response to `ARMu1_CP_FIRST` or `ARMu1_CP_BUSY`)
- `ARMu1_CP_CANT`, to indicate that the instruction is not supported, or the specified register cannot be accessed (only in response to `ARMu1_CP_FIRST` or `ARMu1_CP_BUSY`).
- `ARMu1_CP_LAST`, to indicate that the next load is the last in the sequence. This is only needed for ARM9.

### 4.4.3 STC

This function is called when an STC instruction is recognized for a coprocessor.

#### Syntax

**unsigned** STC(**void** \**handle*, **int** *type*, ARMword *instr*, ARMword \**data*)

where:

<i>handle</i>	is the handle from <code>ARMu1if_InstallCoprocesorV5</code> .								
<i>type</i>	is the type of the coprocessor access. This can be one of: <table border="0"> <tr> <td><code>ARMu1_CP_FIRST</code></td><td>indicates that this is the first time the coprocessor model has been called for this instruction.</td></tr> <tr> <td><code>ARMu1_CP_BUSY</code></td><td>indicates that this is a subsequent call, after the first call was busy-waited.</td></tr> <tr> <td><code>ARMu1_CP_INTERRUPT</code></td><td>warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later. In that case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code>.</td></tr> <tr> <td><code>ARMu1_CP_DATA</code></td><td>indicates that the coprocessor must return valid data in *<i>data</i>.</td></tr> </table>	<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.	<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.	<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later. In that case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .	<code>ARMu1_CP_DATA</code>	indicates that the coprocessor must return valid data in * <i>data</i> .
<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.								
<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.								
<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later. In that case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .								
<code>ARMu1_CP_DATA</code>	indicates that the coprocessor must return valid data in * <i>data</i> .								
<i>instr</i>	is the current opcode.								
<i>data</i>	is a pointer to the location of the data being saved to memory.								

#### Return

The function must return one of:

- `ARMu1_CP_INC`, to indicate that there is more data to transfer to the core (only in response to `ARMu1_CP_FIRST`, `ARMu1_CP_BUSY`, or `ARMu1_CP_DATA`)
- `ARMu1_CP_DONE`, to indicate that the coprocessor operation is complete (only in response to `ARMu1_CP_DATA`)
- `ARMu1_CP_BUSY`, to indicate that the coprocessor is busy (only in response to `ARMu1_CP_FIRST` or `ARMu1_CP_BUSY`)
- `ARMu1_CP_CANT`, to indicate that the instruction is not supported, or the specified register cannot be accessed (only in response to `ARMu1_CP_FIRST` or `ARMu1_CP_BUSY`).
- `ARMu1_CP_LAST`, to indicate that the next save is the last in the sequence. This is only needed for ARM9.

#### 4.4.4 MRC

This function is called when an MRC instruction is recognized for a coprocessor. If the requested coprocessor register does not exist or cannot be written to, the function must return `ARMu1_CP_CANT`.

##### Syntax

```
unsigned MRC(void *handle, int type, ARMword instr, ARMword *data)
```

where:

<i>handle</i>	is the handle from <code>ARMu1if_InstallCoproprocessorV5</code> .								
<i>type</i>	is the type of the coprocessor access. This can be one of: <table border="0"> <tr> <td><code>ARMu1_CP_FIRST</code></td><td>indicates that this is the first time the coprocessor model has been called for this instruction.</td></tr> <tr> <td><code>ARMu1_CP_BUSY</code></td><td>indicates that this is a subsequent call, after the first call was busy-waited.</td></tr> <tr> <td><code>ARMu1_CP_INTERRUPT</code></td><td>warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code>.</td></tr> <tr> <td><code>ARMu1_CP_DATA</code></td><td>indicates that valid data is included in *<i>data</i>.</td></tr> </table>	<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.	<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.	<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .	<code>ARMu1_CP_DATA</code>	indicates that valid data is included in * <i>data</i> .
<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.								
<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.								
<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .								
<code>ARMu1_CP_DATA</code>	indicates that valid data is included in * <i>data</i> .								
<i>instr</i>	is the current opcode.								
<i>data</i>	is a pointer to the location of the data being transferred from the coprocessor to the core.								

##### Return

The function must return one of:

- `ARMu1_CP_DONE`, to indicate that the coprocessor operation is complete, and valid data has been returned to \**data*.
- `ARMu1_CP_BUSY`, to indicate that the coprocessor is busy
- `ARMu1_CP_CANT`, to indicate that the instruction is not supported, or the specified register cannot be accessed.

#### 4.4.5 MCR

This function is called when an MCR instruction is recognized for a coprocessor. If the requested coprocessor register does not exist or cannot be written to, the function must return `ARMu1_CP_CANT`.

##### Syntax

**unsigned** MCR(**void** \**handle*, **int** *type*, ARMword *instr*, ARMword \**data*)

where:

*handle* is the handle from `ARMu1if_InstallCoprocesorV5`.

*type* is the type of the coprocessor access. This can be one of:

<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.
<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.
<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .
<code>ARMu1_CP_DATA</code>	indicates valid data is included in <i>data</i> .

*instr* is the current opcode.

*data* is a pointer to the data being transferred to the coprocessor.

##### Return

The function must return one of:

- `ARMu1_CP_DONE`, to indicate that the coprocessor operation is complete
- `ARMu1_CP_BUSY`, to indicate that the coprocessor is busy
- `ARMu1_CP_CANT`, to indicate that the instruction is not supported, or the specified register cannot be accessed.



### 4.4.6 MCRR

This function is called when an MCRR instruction is recognized for a coprocessor.

The function must return `ARMu1_CP_CANT` if:

- the requested coprocessor register does not exist
- the requested coprocessor register cannot be written to
- the coprocessor is ARM architecture v4T or earlier.

#### Syntax

```
unsigned MCRR(void *handle, int type, ARMword instr, ARMword *data)
```

where:

*handle* is the handle from `ARMu1if_InstallCoprocessorV5`.

*type* is the type of the coprocessor access. This can be one of:

<code>ARMu1_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.
<code>ARMu1_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.
<code>ARMu1_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> .
<code>ARMu1_CP_DATA</code>	indicates valid data is included in <i>data</i> .

*instr* is the current opcode.

*data* is a pointer to the data being transferred to the coprocessor.

#### Return

The function must return one of:

- `ARMu1_CP_DONE`, to indicate that the coprocessor operation is complete
- `ARMu1_CP_BUSY`, to indicate that the coprocessor is busy
- `ARMu1_CP_CANT`, to indicate that the instruction is not supported, or the specified register cannot be accessed.

#### 4.4.7 MRRC

This function is called when an MRRC instruction is recognized for a coprocessor.

The function must return `ARMul_CP_CANT` if:

- the requested coprocessor register does not exist
- the requested coprocessor register cannot be read from
- the coprocessor is ARM architecture v4T or earlier.

#### Syntax

**unsigned** MRRC(**void** \**handle*, **int** *type*, **ARMword** *instr*, **ARMword** \**data*)

where:

*handle* is the handle from `ARMulif_InstallCoprocesorV5`.

*type* is the type of the coprocessor access. This can be one of:

<code>ARMul_CP_FIRST</code>	indicates that this is the first time the coprocessor model has been called for this instruction.
<code>ARMul_CP_BUSY</code>	indicates that this is a subsequent call, after the first call was busy-waited.
<code>ARMul_CP_INTERRUPT</code>	warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMul_CP_FIRST</code> .
<code>ARMul_CP_DATA</code>	indicates valid data is included in <i>data</i> .

*instr* is the current opcode.

*data* is a pointer to the data being transferred from the coprocessor.

#### Return

The function must return one of:

- `ARMul_CP_DONE`, to indicate that the coprocessor operation is complete
- `ARMul_CP_BUSY`, to indicate that the coprocessor is busy
- `ARMul_CP_CANT`, to indicate that the instruction is not supported, or the specified register cannot be accessed.

### 4.4.8 CDP

This function is called when a CDP instruction is recognized for a coprocessor. If the requested coprocessor operation is not supported, the function must return `ARMu1_CP_CANT`.

#### Syntax

**unsigned** CDP(**void** \**handle*, **int** *type*, **ARMword** *instr*, **ARMword** \**data*)

where:

*handle* is the handle from `ARMu1if_InstallCoproprocessorV5`.

*type* is the type of the coprocessor access. This can be one of:

- |                                 |  |
|---------------------------------|--|
| <code>ARMu1_CP_FIRST</code>     | indicates that this is the first time the coprocessor model has been called for this instruction.  |
| <code>ARMu1_CP_BUSY</code>      | indicates that this is a subsequent call, after the first call was busy-waited.  |
| <code>ARMu1_CP_INTERRUPT</code> | warns the coprocessor that the ARM is about to service an interrupt, so the coprocessor must discard the current instruction. Usually, the instruction will be retried later, in which case the <i>type</i> will be reset to <code>ARMu1_CP_FIRST</code> . |

*instr* is the current opcode.

*data* is not used.

#### Return

The function must return one of:

- `ARMu1_CP_DONE`, to indicate that the coprocessor operation is complete
- `ARMu1_CP_BUSY`, to indicate that the coprocessor is busy
- `ARMu1_CP_CANT`, to indicate that the instruction is not supported.

#### 4.4.9 read

This function enables a debugger to read a coprocessor register via RDI. The function reads the coprocessor register numbered *reg* and transfers its value to the location addressed by *value*.

If the requested coprocessor register does not exist, or the register cannot be read, the function must return `ARMul_CP_CANT`.

##### Syntax

```
unsigned read(void *handle, int reg, ARMword instr, ARMword *value)
```

where:

*handle* is the handle from `ARMulif_InstallCoprocesorV5`.

*reg* is the register number of the coprocessor register to be read.

*instr* is not used.

*value* is a pointer to the location of the data to be read from the coprocessor.

##### Return

The function must return one of:

- `ARMul_CP_DONE`, to indicate that the coprocessor operation is complete
- `ARMul_CP_CANT`, to indicate that the register is not supported.

##### Usage

This function is called by the debugger via RDI.

#### 4.4.10 write

This function enables a debugger to write to a coprocessor register via RDI.

The function writes the value at the location addressed by *value* to the coprocessor register numbered *reg*.

If the requested coprocessor does not exist or the register cannot be written, the function must return `ARMu1_CP_CANT`.

##### Syntax

```
unsigned write(void *handle, int reg, ARMword instr, ARMword *value)
```

where:

<i>handle</i>	is the handle from <code>ARMu1if_InstallCoprocesorV5</code> .
<i>reg</i>	is the register number of the coprocessor register that is to be written.
<i>instr</i>	is not used.
<i>value</i>	is a pointer to the location of the data that is to be written to the coprocessor.

##### Return

The function must return one of:

- `ARMu1_CP_DONE`, to indicate that the coprocessor operation is complete
- `ARMu1_CP_CANT`, to indicate that the register is not supported.

##### Usage

This function is called by the debugger via RDI.

## 4.5 Exceptions

The following functions enable a model to set or clear signals:

- *ARMulif\_SetSignal*
- *ARMulif\_GetProperty* on page 4-27.

### 4.5.1 ARMulif\_SetSignal

The ARMulif\_SetSignal function is used to set the state of signals or properties.

#### Syntax

```
void ARMulif_SetSignal(RDI_ModuleDesc *mdesc, ARMSignalType sigType,
                      SignalState sigState)
```

where:

*mdesc* is the handle for the core.

*sigtype* is the signal to be set. *sigtype* can be any one of:

RDIPropID\_ARMSignal\_IRQ

Assert an interrupt.

RDIPropID\_ARMSignal\_FIQ

Assert a fast interrupt.

RDIPropID\_ARMSignal\_RESET

Assert the reset signal. The core will reset, and will not restart until the reset signal is de-asserted.

RDIPropID\_ARMSignal\_BigEnd

Set this signal for big-endian operation, or clear it for little-endian operation.

RDIPropID\_ARMSignal\_HighException

Set the base location of exception vectors.

RDIPropID\_ARMSignal\_BranchPredictEnable

(ARM10 only)

RDIPropID\_ARMSignal\_LDRSetTBITDisable

(ARM10 only)

RDIPropID\_ARMSignal\_WaitForInterrupt

(ARM10 and XScale only)

RDIPropID\_ARMSignal\_DebugState

Enter or exit debug state.

RDIPropID\_ARMu1Prop\_CycleDelta

Wait the core for a specified number of cycles.

RDIPropID\_ARMu1Prop\_Accuracy

Select the modelling accuracy, as a percentage in the range 0% to 100%. Currently this only affects ARM10 models. A setting less than 50% turns off interlock modelling. ARMulator runs faster with interlock modelling turned off, but cycling count accuracy is reduced.

*sigstate* For signals, you must give *sigstate* one of the following values:

FALSE Signal off

TRUE Signal on.

For properties, you must give *sigstate* an integer value.

#### ———— **Note** ————

For information about signalling interrupts when using an interrupt controller see *Interrupt controller* on page 4-75.

## 4.5.2 ARMulif\_GetProperty

The ARMulif\_GetProperty function is used to read the values of properties and signals.

### Syntax

```
void ARMulif_GetProperty(RDI_ModuleDesc *mdesc, ARMSignalType id,
                        ARMword *value)
```

where:

*mdesc* is the handle for the core.

*id* is the signal or property to read. *id* can be any one of:

RDIPropID\_ARMSignal\_IRQ

TRUE if the interrupt signal is asserted.

RDIPropID\_ARMSignal\_FIQ

TRUE if the fast interrupt signal is asserted.

RDIPropID\_ARMSignal\_RESET

TRUE if the reset signal is asserted.

RDIPropID\_ARMSignal\_BigEnd

TRUE if the bigend signal is asserted.

	RDIPropID_ARMSignal_HighException	TRUE if the vector table is at 0xFFFF0000.
	RDIPropID_ARMSignal_BranchPredictEnable	(ARM10 only)
	RDIPropID_ARMSignal_LDRSetTBITDisable	(ARM10 only)
	RDIPropID_ARMSignal_WaitForInterrupt	(ARM10 and XScale only)
	RDIPropID_ARMu1Prop_CycleCount	Count of the number of cycles executed since initialization.
	RDIPropID_ARMu1Prop_RDILog	Current setting of the RDI log level. Generally, this is zero if logging is disabled, and nonzero if it is enabled.
	RDIPropID_ARMSignal_ProcessorProperties	The properties word associated with the processor being simulated. This is a bitfield of properties, defined in <code>armdefs.h</code> .
<i>value</i>		is a pointer to a block to write the property to. This allows for properties with more than 32 bits. However, all the properties listed are actually 32 bits wide at most.



## 4.6 Events

ARMulator has a mechanism for broadcasting and handling events. These events consist of an event number and a pair of words. The number identifies the event. The details depends on the event.

The core ARMulator generates some example events, defined in `armdefs.h`. They are divided into three groups:

- events from the ARM processor core, listed in Table 4-2 on page 4-30
- events from the MMU and cache (not on StrongARM<sup>®</sup>-110), listed in Table 4-1
- events from the prefetch unit (ARM8<sup>™</sup>-based processors only), listed in Table 4-3 on page 4-30
- configuration change events, listed in Table 4-5 on page 4-31.

These events can be logged in the trace file if tracing is enabled, and trace events is turned on. Additional modules can provide new event types that will be handled in the same way. User defined events must have values between `UserEvent_Base` (0x100000) and `UserEvent_Top` (0x1FFFFFF).

You can catch events by installing an event handler (see *Event handler* on page 4-37). You can raise an event by calling `ARMulif_RaiseEvent()` (see *ARMulif\_RaiseEvent* on page 4-32).

**Table 4-1 Events from the MMU and cache (not on StrongARM-110)**

Event name	Word 1	Word 2	Event number
MMUEvent_DLineFetch	Miss address	Victim address	0x10001
MMUEvent_ILineFetch	Miss address	Victim address	0x10002
MMUEvent_WBStall	Physical address of write	Number of words in write buffer	0x10003
MMUEvent_DTLBWalk	Miss address	Victim address	0x10004
MMUEvent_ITLBWalk	Miss address	Victim address	0x10005
MMUEvent_LineWB	Miss address	Victim address	0x10006
MMUEvent_DCacheStall	Address causing stall	Address fetching	0x10007
MMUEvent_ICacheStall	Address causing stall	Address fetching	0x10008

**Table 4-2 Events from the ARM processor core**

Event name	Word 1	Word 2	Event number
CoreEvent_Reset	-	-	0x1
CoreEvent_UndefinedInstr	pc value	Instruction	0x2
CoreEvent_SWI	pc value	SWI number	0x3
CoreEvent_PrefetchAbort	pc value	-	0x4
CoreEvent_DataAbort	pc value	Aborting address	0x5
CoreEvent_AddrExceptn	pc value	Aborting address	0x6
CoreEvent_IRQ	pc value	-	0x7
CoreEvent_FIQ	pc value	-	0x8
CoreEvent_Breakpoint	pc value	RDI_PointHandle	0x9
CoreEvent_Watchpoint	pc value	Watch address	0xA
CoreEvent_IRQSpotted	pc value	-	0x17
CoreEvent_FIQSpotted	pc value	-	0x18
CoreEvent_ModeChange	pc value	New mode	0x19
CoreEvent_Dependency	pc value	Interlock register bitmask	0x20

**Table 4-3 Events from the prefetch unit (ARM810 only)**

Event name	Word 1	Word 2	Event number
PUEvent_Full	Next pc value	-	0x20001
PUEvent_Mispredict	Address of branch	-	0x20002
PUEvent_Empty	Next pc value	-	0x20003

**Table 4-4 Debug events**

Event name	Word 1	Word 2	Event number
DebugEvent_InToDebug	-	-	0x40001
DebugEvent_OutOfDebug	-	-	0x40002
DebugEvent_DebuggerChangedPC	pc	-	0x40003

**Table 4-5 Config events**

Event name	Word 1	Word 2	Event number
ConfigEvent_AllLoaded	-	-	0x50001
ConfigEvent_Reset	-	-	0x50002
ConfigEvent_VectorsLoaded	-	-	0x50003
ConfigEvent_EndiannessChanged	1 (big end) or 2 (little end)	-	0x50005

### 4.6.1 ARMulif\_RaiseEvent

This function invokes events. The events are passed to the user-supplied event handlers.

#### Syntax

```
void ARMulif_RaiseEvent(RDI_ModuleDesc *mdesc, ARMword event,  
                       ARMword data1, ARMword data2)
```

where:

*mdesc* is the handle for the core.

*event* is one of the event numbers defined in Table 4-1 on page 4-29, Table 4-2 on page 4-30, Table 4-3 on page 4-30, or Table 4-4 on page 4-31.

*data1* is the first word of the event.

*data2* is the second word of the event.

## 4.7 Handlers

ARMulator can be made to call back your model when some state values change. You do this by installing the relevant *event handler*.

You must provide implementations of the event handlers if you want to use them in your own models. See the implementations in the ARM supplied models for examples.

You can use event handlers to avoid having to check state values on every access. For example, a peripheral model is expected to present the ARM core with data in the correct byte order for the value of the ARM processor **bigend** signal. A peripheral model can attach to the `EventHandler()` (see *Event handler* on page 4-37) to be informed when this signal changes.

### 4.7.1 Exception handler

This event handler is called whenever the ARM processor takes an exception.

#### Syntax

```
typedef unsigned GenericCallbackFunc(void *handle, void *data)
```

where:

*handle* is the handle passed to ARMulif\_InstallExceptionHandler.

*data* must be cast to (ARMul\_Event \*), and contain:

```
((ARMul_Event *)data)->event
```

is the core event causing the exception (see Table 4-2 on page 4-30).

```
((ARMul_Event *)data)->data1
```

is the address of the hardware vector for the exception.

```
((ARMul_Event *)data)->data2
```

is the instruction that caused the exception.

#### Usage

As an example, this can be used by an operating system model to intercept and simulate SWIs. If an installed handler returns nonzero, the ARM does not take the exception (the exception is ignored).

#### ————— Note —————

If the processor is in Thumb state, the equivalent ARM instruction will be supplied.

Install the exception handler using:

```
int ARMulif_InstallExceptionHandler(RDI_ModuleDesc *mdesc,  
                                     GenericCallbackFunc *func, void *handle)
```

Remove the exception handler using:

```
int ARMulif_RemoveExceptionHandler(RDI_ModuleDesc *mdesc,  
                                     GenericCallbackFunc *func, void *handle)
```

## 4.7.2 Unknown RDI information handler

The unknown RDI information function is called if ARMulator cannot handle an RDI\_InfoProc request itself. It returns an RDIError value. This function can be used by a model extending the RDI interface between ARMulator and the debugger. For example, the profiler module (in profiler.c) provides the RDIProfile info calls.

### Syntax

```
typedef int RDI_InfoProc(void *handle, unsigned type,
                        ARMword *arg1, ARMword *arg2)
```

where:

*handle* is the handle passed to ARMulif\_InstallUnkRDIInfoHandler.

*type* is the RDI\_InfoProc subcode. These are defined in rdi\_info.h. See below for some examples.

*arg1/arg2* are arguments passed to the handler from ARMulator.

### Usage

ARMulator stops calling RDI\_InfoProc() functions when one returns a value other than RDIError\_UnimplementedMessage.

The following codes are examples of the RDI\_InfoProc subcodes that can be specified as *type*:

#### RDIInfo\_Target

This enables models to declare how to extend the functionality of the target. For example, profiler.c intercepts this call to set the RDITarget\_CanProfile flag.

#### RDIInfo\_SetLog

This is passed around so that models can switch logging information on and off. For example, tracer.c uses this call to switch tracing on and off from bit 4 of the rdi\_log value.

#### RDIRequestCyclesDesc

This enables models to extend the list of counters provided by the debugger in \$statistics. Models call ARMul\_AddCounterDesc() (see *General purpose functions* on page 4-41) to declare each counter in turn. It is essential that the model also trap the RDIcycles RDI info call.

**RDICycles** Models that have declared a statistics counter by trapping **RDIREquestCyclesDesc** must also respond to **RDICycles** by calling **ARMul\_AddCounterValue()** (see *General purpose functions* on page 4-41) for each counter in turn, in the same order as they were declared.

The above RDI info calls have already been dealt with by ARMulator, and are passed for information only, or so that models can add information to the reply. Models must always respond to these messages with **RDIError\_UnimplementedMessage**, so that the message is passed on even if the model has responded.

Install the handler using:

```
int ARMulif_InstallUnkRDIInfoHandler(RDI_ModuleDesc *mdesc,
                                     RDI_InfoProc *func, void *handle)
```

Remove the handler using:

```
int ARMulif_RemoveUnkRDIInfoHandler(RDI_ModuleDesc *mdesc,
                                     RDI_InfoProc *func, void *handle)
```

## Example

The `semihost.c` model supplied with ARMulator uses the `UnkRDIInfoUpcall()` to interact with the debugger:

<b>RDIErrorP</b>	returns errors raised by the program running under ARMulator to the debugger.
<b>RDISet_Cmdline</b>	finds the command line set for the program by the debugger.
<b>RDIVector_Catch</b>	intercepts the hardware vectors.



### 4.7.3 Event handler

This handler catches ARMulator events (see *Events* on page 4-29).

#### Syntax

```
typedef unsigned GenericCallbackFunc(void *handle, void *data)
```

where:

*handle* is the handle passed to ARMulif\_InstallEventHandler.

*data* must be cast to (ARMul\_Event \*), and contain:

```
((ARMul_Event *)data)->event
```

is one of the event numbers defined in Table 4-1 on page 4-29, Table 4-2 on page 4-30, and Table 4-3 on page 4-30.

```
((ARMul_Event *)data)->addr1
```

is the first word of the event.

```
((ARMul_Event *)data)->addr2
```

is the second word of the event.

#### Usage

Install the handler using:

```
void *ARMulif_InstallEventHandler(RDI_ModuleDesc *mdesc, uint32 events,  
                                GenericCallbackFunc *func, void *handle)
```

Specify one or more of the following for *events*:

- CoreEventSel
- MMUEventSel
- PUEventSel
- DebugEventSel
- TraceEventSel
- ConfigEventSel.

Remove the handler using:

```
int ARMulif_RemoveEventHandler(RDI_ModuleDesc *mdesc, void *node)
```

#### Example handler installation

```
ARMulif_InstallEventHandler(mdesc, CoreEventSel | ConfigEventSel, func, handle)
```

## 4.8 Memory access functions

The memory system can be probed by a peripheral model using a set of functions for reading and writing memory. These functions access memory without inserting cycles on the bus. If your model inserts cycles on the bus, it must install itself as a memory model, possibly between the core and the real memory model.

---

**Note**

---

It is not possible to tell if these calls result in a data abort.

---

### 4.8.1 Reading from a given address

The following functions return the word, halfword, or byte at the specified address. Each function accesses the memory without inserting cycles on the bus.

#### Syntax

```
ARMword ARMulif_ReadWord(RDIModuleDesc *mdesc, ARMword address)
```

```
ARMword ARMulif_ReadHalfword(RDIModuleDesc *mdesc, ARMword address)
```

```
ARMword ARMulif_ReadByte(RDIModuleDesc *mdesc, ARMword address)
```

where:

*mdesc* is the handle for the core.

*address* is the address in simulated memory from which the word, halfword, or byte is to be read.

#### Return

The functions return the word, halfword, or byte, as appropriate.

## 4.8.2 Writing to a specified address

The following functions write the specified word, halfword, or byte at the specified address. Each function accesses memory without inserting cycles on the bus.

### Syntax

```
void ARMulif_WriteWord(RDIModuleDesc *mdesc, ARMword address, ARMword data)
void ARMulif_WriteHalfword(RDIModuleDesc *mdesc, ARMword address, ARMword data)
void ARMulif_WriteByte(RDIModuleDesc *mdesc, ARMword address, ARMword data)
```

where:

<i>mdesc</i>	is the handle for the core.
<i>address</i>	is the address in simulated memory to write to.
<i>data</i>	is the word or byte to write.

## 4.9 Event scheduling functions

The following functions enable you to schedule or remove events:

- *ARMulif\_ScheduleTimedFunction*
- *ARMulif\_DescheduleTimedFunction*.

### 4.9.1 ARMulif\_ScheduleTimedFunction

This function schedules events using memory system cycles. It enables a function to be called at a specified number of cycles in the future.

#### Syntax

```
void *ARMulif_ScheduleTimedFunction(RDI_ModuleDesc *mdesc,
                                   ARMul_TimedCallback *tcb)
```

where:

*mdesc* is the handle for the core.

*tcb* is a handle for you to use if you want to deschedule the function.

#### ———— Note ————

The function can be called only on the first instruction boundary following the specified cycle.

### 4.9.2 ARMulif\_DescheduleTimedFunction

ARMul\_DescheduleTimedFunction() removes a previously-scheduled memory cycle based event.

#### Syntax

```
unsigned ARMulif_DescheduleTimedFunction(RDI_ModuleDesc *mdesc, void *tcb);
```

where:

*mdesc* is the handle for the core.

*tcb* is the handle supplied by ARMulif\_ScheduleTimedFunction when the event was first set up.

## 4.10 General purpose functions

The following are general purpose ARMulator functions. They include functions to access processor properties, add counter descriptions and values, stop ARMulator and execute code:

- *ARMul\_BusRegisterPeripFunc*
- *ARMulif\_ReadBusRange* on page 4-44
- *Hostif\_RaiseError* on page 4-45
- *ARMulif\_Time* on page 4-45
- *ARMul\_AddCounterDesc* on page 4-46
- *ARMul\_AddCounterValue* on page 4-47
- *ARMulif\_StopExecution* on page 4-49
- *ARMulif\_EndCondition* on page 4-49
- *ARMulif\_GetCoreClockFreq* on page 4-50.

### 4.10.1 ARMul\_BusRegisterPeripFunc

A peripheral model must call this function to register the peripheral with the ARMulator. This enables ARMulator to call the model whenever it makes accesses to memory locations belonging to the peripheral.

#### Syntax

```
int ARMul_BusRegisterPeripFunc(enum BusRegAct act,
                               ARMul_BusPeripAccessRegistration *breg);
```

where:

*act* is the action you want. *act* must have one of the following values: insert or remove.

*breg* is a structure containing information for the ARMulator. You can obtain this structure by calling *ARMulif\_ReadBusRange* (see *ARMulif\_ReadBusRange* on page 4-44).

*breg* is a structure of type *ARMul\_BusPeripAccessRegistration* (see *ARMul\_BusPeripAccessRegistration* on page 4-42 for details).

## ARMul\_BusPeripAccessRegistration

This structure and type are declared in `armul_bus.h`, in `install_directory\ARMulate\armulif`. The declaration is as follows:

```
typedef struct ARMul_BusPeripAccessRegistration {
    ARMul_BusPeripAccessFunc *access_func;
    void *access_handle;
    uint32 capabilities; /* See PeripAccessCapability_* below */
    struct ARMul_Bus *bus;
    /* 0=> normal peripheral, earlier in list than anything it
     * overlaps with. */
    unsigned priority;
    /* 0..100%
     * A higher number will be placed earlier in the list than
     * anything that it doesn't overlap with and has a lower access_frequency.
     */
    unsigned access_frequency;
    unsigned addr_size; /* Number of elements in range[] */
    AddressRange range[1];
} ARMul_BusPeripAccessRegistration;
```

where:

<i>access_func</i>	Pointer to the function to call for a memory access in the given address range.
<i>access_handle</i>	Pointer to object data for <i>access_func</i> .
<i>capabilities</i>	See <i>PeripAccessCapability</i> on page 4-43.
<i>bus</i>	This is returned by <code>ARMulif_QueryBus</code> . Do not alter it.
<i>priority</i>	Use this field to assign a priority to peripherals. Zero is the highest priority. If peripherals have overlapping address ranges, the highest priority peripheral is accessed first. Lower priority peripherals are only accessed if higher priority peripherals return without processing the call.
<i>access_frequency</i>	Use this field to inform ARMulator which peripheral you expect to be accessed more frequently. This allows ARMulator to access peripherals more efficiently. Assign the frequency as a percentage in the range 0% to 100%.
<i>addr_size</i>	This is for future expansion. 1 is for 32-bit addresses. This is the only address size currently supported.
<i>range</i>	The address range occupied by this peripheral.

## PeripAccessCapability

This parameter defines the capabilities of the peripheral. It is the sum of the values of the individual capabilities (see Table 4-6).

For example:

- A value of 0x20020 means that the peripheral can handle word data accesses, but not bytes, halfwords, or double words, and understands the **Endian** signal. This value is predefined as PeripAccessCapability\_Minimum.
- A value of 0x20038 means that the peripheral can handle byte, halfword, and word data accesses, but not doubleword, and understands the **Endian** signal. This value is predefined as PeripAccessCapability\_Typical.

**Table 4-6 Peripheral access capabilities**

Capability	Predefined name	Value
Byte	PeripAccessCapability_Byte	0x8
Half word	PeripAccessCapability_HWord	0x10
Word	PeripAccessCapability_Word	0x20
Double word	PeripAccessCapability_DWord	0x40
Peripheral accepts idle cycles	PeripAccessCapability_Idles	0x10000 ( <b>unsigned long</b> )
Peripheral understands <b>Endian</b> signal	PeripAccessCapability_Endian	0x20000 ( <b>unsigned long</b> )
Peripheral understands bytelanes	PeripAccessCapability_Bytelane	0x40000 ( <b>unsigned long</b> )

### 4.10.2 ARMulif\_ReadBusRange

You must supply a *breg* structure to register a peripheral. Call this function to initialize the fields in this structure.

#### Syntax

```
int ARMulif_ReadBusRange(struct RDI_ModuleDesc *mdesc,
                        struct RDI_HostosInterface const *hostif,
                        toolconf config,
                        struct ARMul_BusPeripAccessRegistration *breg,
                        uint32 default_base, uint32 default_size,
                        char const *default_bus_name);
```

where:

*mdesc* is the handle for the core.

*hostif* is the handle for the host interface.

*config* is the configuration passed in to your model in BEGIN\_INIT.

*breg* is a structure containing information for the ARMulator. You need this for registerPeripFunc() (see *ARMul\_BusRegisterPeripFunc* on page 4-41). For details of the structure, see armulbus.h in <install\_directory>\armulate\armulif.

*default\_base* is the default base address to use for your peripheral. This address is used if *config* does not contain a base address for your peripheral.

*default\_size* is the default size of the area in memory to use for your peripheral. This is used if *config* does not contain a size for your peripheral.

*default\_bus\_name*

is a pointer to a string. This string is used if no bus name is found in the config parameter for this peripheral, for example in a .dsc or .ami file.



### 4.10.3 Hostif\_RaiseError

Several initialization and installation functions can return errors of type `ARMul_Error`. These errors must be passed through `Hostif_RaiseError()`. This is a `printf`-like function that formats the error message associated with an `ARMul_Error` error code.

`Hostif_RaiseError` only prints the error message. After calling this function, the model must return with an appropriate error, such as `RDIError_UnableToInitialise`.

`Hostif_RaiseError` must only be used during initialization.

#### Syntax

```
void Hostif_RaiseError(const struct RDI_HostosInterface *hostif,
                     const char *format, ...)
```

where:

*hostif* is the handle for the host interface.

*format* is the error code for the error message to be formatted.

... are `printf`-style format specifiers of variadic type.

### 4.10.4 ARMulif\_Time

This function returns the number of memory cycles executed since system reset.

#### Syntax

```
ARMTIME ARMulif_Time(RDI_ModuleDesc *mdesc)
```

where:

*mdesc* is the handle for the core.

#### Return

The function returns the total number of cycles executed since system reset.

#### 4.10.5 ARMul\_AddCounterDesc

The ARMul\_AddCounterDesc() function adds new counters to \$statistics.

##### Syntax

```
int ARMul_AddCounterDesc(void *handle, ARMword *arg1, ARMword *arg2,
                        const char *name)
```

where:

*handle* is no longer used.

*arg1/arg2* are the arguments passed to the UnkRDIInfoUpcall().

*name* is a string that names the statistic counter. The string must be less than 32 characters long.

##### Return

The function returns one of:

- RDIError\_BufferFull
- RDIError\_UnimplementedMessage.

##### Usage

When ARMulator receives an RDIRequestCycleDesc() call from the debugger, it uses the UnkRDIInfoUpcall() (see *Unknown RDI information handler* on page 4-35) to ask each module in turn if it wishes to provide any statistics counters. Each module responds by calling ARMul\_AddCounterDesc() with the arguments passed to the UnkRDIInfoUpcall().

All statistics counters must be either a 32-bit or 64-bit word, and be monotonically increasing. That is, the statistic value must go up over time. This is a requirement because of the way the debugger calculates \$statistics\_inc.

### 4.10.6 ARMu1\_AddCounterValue

This function provides the facility for your model to supply statistics for the debugger to display.

#### Syntax

```
int ARMu1_AddCounterValue(void *handle, ARMword *arg1, ARMword *arg2, bool is64,
                          const ARMword *counter)
```

where:

*handle* is no longer used.

*arg1/arg2* are the arguments passed to the UnkRDIInfoUpcall().

*is64* denotes whether the counter is a pair of 32-bit words making a 64-bit counter (least significant word first), or a single 32-bit value. This enables modules to provide a full 64-bit counter.

*counter* is a pointer to the current value of the counter.

#### Return

The function always returns `RDIError_UnimplementedMessage`.

#### Usage

Your model must call this function, or `ARMu1_AddCounterValue64`, from its `UnkRDIInfoUpcall()` handler. `ARMu1_AddCounterValue64` is identical to `ARMu1_AddCounterValue` except for the word order of the counter.

#### 4.10.7 ARMul\_AddCounterValue64

This function provides the facility for your model to supply statistics for the debugger to display.

##### Syntax

```
int ARMul_AddCounterValue64(void *handle, ARMword *arg1, ARMword *arg2,  
                           const uint64 counterval)
```

where:

*handle* is no longer used.

*arg1/arg2* are the arguments passed to the UnkRDIInfoUpcall().

*counterval* is the current value of the counter.

##### Return

The function always returns RDIError\_UnimplementedMessage.

##### Usage

Your model must call this function, or ARMul\_AddCounterValue, from its UnkRDIInfoUpcall() handler. This function is identical to ARMul\_AddCounterValue except that the word order is big-endian or little-endian according to the word order of the host system.

### 4.10.8 ARMulif\_StopExecution

This function stops simulator execution at the end of the current instruction, giving a reason code.

#### Syntax

```
void ARMulif_StopExecution(RDI_ModuleDesc *mdesc, unsigned reason)
```

where:

<i>mdesc</i>	is the handle for the core.
<i>reason</i>	is an RDIError error value. The debugger interprets <i>reason</i> and issues a suitable message. Expected errors are:
RDIError_NoError	Program ran to a natural termination.
RDIError_BreakpointReached	Stop condition was a breakpoint.
RDIError_WatchPointReached	Stop condition was a watchpoint.
RDIError_UserInterrupt	Execution interrupted by the user.

### 4.10.9 ARMulif\_EndCondition

This function returns the *reason* passed to ARMulif\_StopExecution.

#### Syntax

```
unsigned ARMulif_EndCondition(RDI_ModuleDesc *mdesc)
```

where:

<i>mdesc</i>	is the handle for the core.
--------------	-----------------------------

#### 4.10.10 ARMulif\_GetCoreClockFreq

This function returns the CPUSPEED in Hertz.

##### **Syntax**

```
ARMTIME ARMulif_GetCoreClockFreq(RDI_ModuleDesc *mdesc)
```

where:

*mdesc* is the handle for the core.

#### 4.10.11 ARMulif\_InstallHourglass

Use this function to install an hourglass callback from ARMulator to your model.

##### Syntax

```
void *ARMulif_InstallHourglass(RDI_ModuleDesc *mdesc,  
                               armul_Hourglass *newHourglass, void *handle);
```

where:

*mdesc* is the handle for the core.

*newHourglass* is a function of type `armul_Hourglass`. You can find the prototype for `armul_Hourglass` in `armul_types.h`, in *install\_directory\ARMulate\armulif*.

*handle* is a pointer to the data required by your function, *newHourglass*.

##### Usage

When you install an hourglass, ARMulator gives your model a callback each time an instruction is executed.

##### Return

This function returns a handle for your model to use to remove the hourglass callback.

#### 4.10.12 ARMulif\_RemoveHourglass

Use this function to remove an hourglass callback.

##### Syntax

```
int ARMulif_RemoveHourglass(RDI_ModuleDesc *mdesc, void *node);
```

where:

*mdesc* is the handle for the core.

*node* is the handle returned by `ARMulif_InstallHourglass`.

## 4.11 Accessing the debugger

This section describes the input, output, and RDI functions that you can use to access the debugger.

Several functions are provided to display messages in the host debugger. Under *armsd*, these functions print messages to the console. Under *AXD*, they display messages to the relevant window:

- *Hostif\_DebugPrint*
- *Hostif\_ConsolePrint* on page 4-53
- *Hostif\_PrettyPrint* on page 4-53
- *Hostif\_DebugPause* on page 4-56.

All of these functions take the following as the first parameter:

```
const struct RDI_HostosInterface *hostif
```

This value is available in the state datastructure of the model, as defined between the *BEGIN\_STATE\_DECL()* and *END\_STATE\_DECL()* macros (see *Basic model interface* on page 4-12).

### 4.11.1 Hostif\_DebugPrint

This function displays a message in the RDI logging window under a GUI debugger, or to the console under *armsd*.

#### Syntax

```
void Hostif_DebugPrint(const struct RDI_HostosInterface *hostif,  
                      const char *format, ...)
```

where:

- hostif* is the handle for the host interface.
- format* is a pointer to a printf-style formatted output string.
- ... are a variable number of parameters associated with *format*.



### 4.11.2 Hostif\_ConsolePrint

This function prints the text specified in the format string to the ARMulator console. Under AXD, the text appears in the console window.

#### Syntax

```
void Hostif_ConsolePrint(const struct RDI_HostosInterface *hostif,
                        const char *format, ...)
```

where:

*hostif* is the handle for the host interface.

*format* is a pointer to a printf-style formatted output string.

... are a variable number of parameters associated with *format*.

---

#### Note

---

Use Hostif\_PrettyPrint() to display startup messages.

---

### 4.11.3 Hostif\_PrettyPrint

This function prints a string in the same way as Hostif\_ConsolePrint(), but in addition performs line-break checks so that wordwrap is avoided. Use it to display startup messages.

#### Syntax

```
void Hostif_PrettyPrint(const struct RDI_HostosInterface *hostif,
                       struct hashblk * /*toolconf*/ config,
                       const char *format, ...)
```

where:

*hostif* is the handle for the host interface.

*config* is a pointer to the toolconf configuration database of the model. This value is available in the state datastructure of the model, as defined between the BEGIN\_STATE\_DECL() and END\_STATE\_DECL() macros (see *Basic model interface* on page 4-12).

*format* is a pointer to a printf-style formatted output string.

... are a variable number of parameters associated with *format*.

#### 4.11.4 Hostif\_ConsoleReadC

This function reads a character from the ARMulator console.

##### Syntax

```
int Hostif_ConsoleReadC(const struct  
                        RDI_HostosInterface *hostif)
```

where:

*hostif* is the handle for the host interface.

##### Return

This function returns the ASCII value of the character read, or EOF.

#### 4.11.5 Hostif\_WriteC

This function writes a character to the ARMulator console.

##### Syntax

```
void Hostif_ConsoleWriteC(const struct  
                          RDI_HostosInterface *hostif, int c)
```

where:

*hostif* is the handle for the host interface.

*c* is the character to write. *c* is converted to an unsigned char.

#### 4.11.6 Hostif\_ConsoleRead

This function reads a string from the ARMulator console. Reading terminates at a newline or if the end of the buffer is reached.

##### Syntax

```
char *Hostif_ConsoleRead(const struct RDI_HostosInterface *hostif,
                        char *buffer, int len)
```

where:

*hostif* is the handle for the host interface.

*buffer* is a pointer to a buffer to hold the string.

*len* is the maximum length of the buffer.

##### Return

This function returns a pointer to a buffer, or NULL on error or end of file.

The buffer contains at most *len*-1 characters, terminated by a zero. If a newline is read, it is included in the string before the zero.

#### 4.11.7 Hostif\_ConsoleWrite

This function writes a string to the ARMulator console.

##### Syntax

```
int Hostif_ConsoleWrite(const struct RDI_HostosInterface *hostif,
                       const char *buffer, int len)
```

where:

*hostif* is the handle for the host interface.

*buffer* is a pointer to a buffer holding a zero-terminated string.

*len* is the length of the buffer.

##### Return

This function returns the number of characters actually written. This is *len* unless an error occurs.

#### 4.11.8 Hostif\_DebugPause

This function waits for the user to press any key.

##### Syntax

```
void Hostif_DebugPause(const struct RDI_HostosInterface *hostif)
```

where:

*hostif* is the handle for the host interface.

## 4.12 Tracer

This section describes the functions provided by the tracer module, `tracer.c`.

---

**Note**

---

These functions are not exported. If you want to use any of these functions in your model, you must build your model together with `tracer.c`.

---

The default implementations of these functions can be changed by compiling `tracer.c` with `EXTERNAL_DISPATCH` defined.

The formats of `Trace_State` and `Trace_Packet` are documented in `tracer.h`.

### 4.12.1 Tracer\_Open

This function is called when the tracer is initialized.

**Syntax**

```
unsigned Tracer_Open(Trace_State *ts)
```

**Usage**

The implementation in `tracer.c` opens the output file from this function, and writes a header.

### 4.12.2 Tracer\_Dispatch

This function is called on each traced event for every instruction, event, or memory access.

**Syntax**

```
void Tracer_Dispatch(Trace_State *ts, Trace_Packet *packet)
```

**Usage**

In `tracer.c`, this function writes the packet to the trace file.

### 4.12.3 Tracer\_Close

This function is called at the end of tracing.

#### Syntax

```
void Tracer_Close(Trace_State *ts)
```

#### Usage

The file `tracer.c` uses this to close the trace file.

### 4.12.4 Tracer\_Flush

This function is called when tracing is disabled.

#### Syntax

```
extern void Tracer_Flush(Trace_State *ts)
```

#### Usage

The file `tracer.c` uses this to flush output to the trace file.

## 4.13 Map files

The type and speed of memory in a simulated system can be detailed in a map file. A map file defines the number of regions of attached memory, and for each region:

- the address range to which that region is mapped
- the data bus width in bytes
- the access time for the memory region.

armsd expects the map file to be called armsd.map, in the current working directory.

AXD accepts map files of any name. See *AXD and armsd Debuggers Guide* for details of how to use a particular map file in a debugging session.

To calculate the number of wait states for each possible type of memory access, the ARMulator uses the access times supplied in the map file, and the clock frequency from the debugger (see *AXD and armsd Debuggers Guide*).

See also *Memory modelling with mapfiles* on page 2-27.

---

### Note

---

A memory map file defines the characteristics of the memory areas defined in peripherals.amr (see *ARMulator configuration files* on page 4-63). A .map file must define rw areas that are at least as large as those specified for the heap and stack in peripherals.amr, and at the same locations. If this is not the case, Data Aborts are likely to occur during execution.

---

### 4.13.1 Format of a map file

The format of each line is:

```
start size name width access{*} read-times write-times
```

where:

<i>start</i>	is the start address of the memory region in hexadecimal, for example 80000.
<i>size</i>	is the size of the memory region in hexadecimal, for example, 4000.
<i>name</i>	is a single word that you can use to identify the memory region when memory access statistics are displayed. You can use any name. To ease readability of the memory access statistics, give a descriptive name such as SRAM, DRAM, or EPROM.

*width* is the width of the data bus in bytes (that is, 1 for an 8-bit bus, 2 for a 16-bit bus, or 4 for a 32-bit bus).

*access* describes the type of accesses that can be performed on this region of memory:

r for read-only.

w for write-only.

rw for read-write.

- for no access. Any access causes a Data or Prefetch Abort.

An asterisk (\*) can be appended to *access* to describe a Thumb-based system that uses a 32-bit data bus to memory, but which has a 16-bit latch to latch the upper 16 bits of data, so that a subsequent 16-bit sequential access can be fetched directly out of the latch.

*read-times*

describes the nonsequential and sequential read times in nanoseconds. These must be entered as the nonsequential read access time followed by a slash (/), followed by the sequential read access time. Omitting the slash and using only one figure indicates that the nonsequential and sequential access times are the same.

———— **Note** —————

For accurate modelling of real devices, you might have to add a signal propagation delay (20 to 30ns) to the read and write times quoted for a memory chip.

*write-times*

describes the nonsequential and sequential write times. The format is the same as that given for read times.

The following examples assume a clock speed of 20MHz, the default.

### Example 1

```
0 80000000 RAM 4 rw 135/85 135/85
```

This describes a system with a single continuous section of RAM from 0 to 0x7FFFFFFF with a 32-bit data bus, read-write access, nonsequential access time of 135ns, and sequential access time of 85ns.



## Example 2

This example describes a typical embedded system with 32KB of on-chip memory, 16-bit ROM and 32KB of external DRAM:

```
00000000 8000 SRAM 4 rw 1/1 1/1
00008000 8000 ROM 2 r 100/100 100/100
00010000 8000 DRAM 2 rw 150/100 150/100
7FFF8000 8000 Stack 2 rw 150/100 150/100
```

There are four regions of memory:

- A fast region from 0 to 0x7FFF with a 32-bit data bus. This is labeled SRAM.
- A slower region from 0x8000 to 0xFFFF with a 16-bit data bus. This is labelled ROM and contains the image code. It is marked as read-only.
- A region of RAM from 0x10000 to 0x17FFF that is used for image data.
- A region of RAM from 0x7FFF8000 to 0x7FFFFFFF that is used for stack data. The stack pointer is initialized to 0x80000000.

In the final hardware, the two distinct regions of the external DRAM are combined. This does not make any difference to the accuracy of the simulation.

To represent fast (no wait state) memory, the SRAM region is given access times of 1ns. In effect, this means that each access takes 1 clock cycle, because ARMulator rounds this up to the nearest clock cycle. However, specifying it as 1ns allows the same map file to be used for a number of simulations with differing clock speeds.

### Note

To ensure accurate simulations, make sure that all areas of memory likely to be accessed by the image you are simulating are described in the memory map.

To ensure that you have described all areas of memory that you think the image accesses, you can define a single memory region that covers the entire address range as the last line of the map file. For example, you could add the following line to the above description:

```
00000000 80000000 Dummy 4 - 1/1 1/1
```

You can then detect if any reads or writes are occurring outside the regions of memory you expect using the print \$memory\_statistics command.

### Note

A dummy memory region must be the *last* entry in a map file.

## Reading the memory statistics

To read the memory statistics use the command:

```
print $memory_statistics
```

print \$memstats is a short version of print \$memory\_statistics.

Example 4-1 shows the form of reports given.

### Example 4-1

---

address	name	W acc	R(N/S)	W(N/S)	reads(N/S)	writes(N/S)	time (ns)
00000000	Dummy	4 -	1/1	1/1	0/0	0/0	0
7FFF8000	Stack	2 rw	150/100	150/100	9290/10590	4542/11688	8538300
00010000	DRAM	2 rw	150/100	150/100	18817/18	11031/140	8915800
00008000	ROM	2 r	100/100	100/100	48638/176292	0/0	44817000
00000000	SRAM	4 rw	1/1	1/1	0/0	0/0	0

---

The report in Example 4-1 shows that:

- ROM access is critical to this application. Consider using faster ROM, using burst-capable ROM, or making the ROM wider (32 bits).
- No use was made of SRAM at 0x0. Consider locating the stack, or other data at 0x0.

## 4.14 ARMulator configuration files

This section contains the following subsections:

- *Predefined tags* on page 4-64
- *Processors* on page 4-64
- *Changing the cache or TCM size of a synthesizable processor* on page 4-66.

ARMulator configuration files (.ami files) are ToolConf files. See *ToolConf* on page 4-68.

Depending on your system, these are located in one of:

- *install\_directory\Bin*
- *install\_directory/linux/bin*
- *install\_directory/solaris/bin*
- *install\_directory/hpux/bin.*

You can make copies of .ami files, and edit them. Make a suitable directory for your new .ami files, and add its path to the ARMCONF environment variable. Ensure that your directory appears before the bin directory in ARMCONF.

By default, there are the following .ami files, all in the Bin directory:

- *bustypes.ami*
- *default.ami*
- *example1.ami*
- *peripherals.ami*
- *processors.ami*
- *vfp.ami*

ARMulator loads all .ami files it finds on any of the paths it finds in the environment variable ARMCONF. This is initially set up to point to *install\_directory\Bin* or *install\_directory/arch/bin*.

If a configuration is specified differently in two files, the *first* specification is used. If there are several directories in ARMCONF, ARMulator loads .ami files from directories in the order that they appear in the list. ARMulator loads .ami files from within each directory in an unpredictable order.

4.14.1 Predefined tags

Before reading .ami files, ARMulator creates several tags itself, based on the settings you give to the debugger. These are given in Table 4-7. Preprocessing directives in .ami files use these tags to control the configuration.

Table 4-7 Tags predefined by ARMulator

Tag	Description
CPUSpeed	Set to the speed set in the configuration window of AXD, or in the -clock command line option for armsd. For example, CPUSpeed=30MHz.
FCLK	Set to the same value as CPUSpeed, if that value is not zero. Not set if CPUSpeed is zero.
MCLK	Set to the same value as FCLK for uncached cores. Set to FCLK/MCCFG for cached cores.
ByteSex	Set to L or B if a bytesex is specified from the debugger. Not set otherwise.
FPE	Set to True or False from the debugger.

4.14.2 Processors

The processors region is a child ToolConf database (see *ToolConf* on page 4-68). It has a full list of processors supported by the ARMulator. This list is the basis of the list of processors in AXD, and the list of accepted arguments for the -processor option of armsd.

You can add a variant processor to this list, for example to include a particular memory model in the definition. See *install\_directory\Bin\example1.ami* for examples.

Default specifies the processor to use if no other processor is specified. Each other entry in the Processors region is the name of a processor.

Example 4-2 on page 4-65 declares two processors, TRACED\_ARM10 and PROFILED\_ARM7. In this example, MCCFG is the ratio of the clock frequency on the processor to the clock frequency on the external bus.

**Example 4-2 Processors in a toolconf file**


---

```

{Processors

  {TRACED_ARM10=ARM10200E

    ;CPUSPEED=400MHz

    ;Memory clock divisor.
    ;(The AHB runs this many times slower than the core.)
    MCCFG=4

    {Flatmem
      {Peripherals
        {Tracer=Default_Tracer
          ;; Output options - can be plaintext to file, binary to file or to RDI
log          ;; window. (Checked in the order RDIlog, File, BinFile.)
          RDIlog=False
          File=armul.trc
          BinFile=armul.trc
          ;; Tracer options - what to trace
          TraceInstructions=True
          TraceRegisters=False
          TraceMemory=True
          TraceEvents=False
          ;; Flags - disassemble instructions; start up with tracing enabled.
          Disassemble=True
          StartOn=True
        }
      }
    }

    ;End TRACED_ARM10
  }

  {PROFILED_ARM7=ARM720T
    {Flatmem
      {Peripherals
        {Profiler=Default_Profiler
        }
      }
    }
  }

;End Processors
}

```

---

## Finding the configuration for a selected processor

ARMulator uses the following algorithm to find a configuration for a selected processor:

1. Set the current region to be Processors.
2. Find the selected processor in the current region.
3. If the tag has a child, that child is the required configuration.

## Adding a variant processor model

Suppose you have created a memory model called MyASIC, designed to be combined with an ARM7TDMI® processor core to make a new microcontroller called ARM7TASIC. To allow this to be selected from AXD, or armsd, add a .ami file modeled on example1.ami.

### 4.14.3 Changing the cache or TCM size of a synthesizable processor

To change the cache or TCM size of a synthesizable processor, make a copy of the processors.ami file, place it in the appropriate directory (see *ARMulator configuration files* on page 4-63), and edit it.

For example, to change both caches of the ARM946E-S to 8KB:

1. Find the following lines in your copy of the processors.ami file:
 

```
{ARM946E-S=ARM946E-S-REV1
}
```
2. Insert lines so that this section reads:
 

```
{ARM946E-S=ARM946E-S-REV1
ICache_Lines=256
DCache_Lines=256
}
```

This overrides the corresponding lines in armulate.dsc.

#### ———— Caution ————

Any cores that inherit properties from ARM946E-S, such as ARM946E-S-ETM-(L), ARM946E-S-ETM-(M), or ARM946E-S-ETM-(S), are also affected if you make this change.

Cores that do not inherit their properties from ARM946E-S, such as ARM946E-S-REV0 or ARM946E-S-REV1 are not affected.

If you want to change the cache or TCM size of a processor that does not already have a section in `processors.ami`, you can add a section. For example, to change the instruction RAM size of the ARM926EJ-S from 64KB to 32KB:

1. Find the following lines at the end of your copy of the `processors.ami` file:

```
{ARM926EJ-S=ARM926EJ-S-REV0
}
```

```
;End of Processors
```

2. Insert lines so that this becomes:

```
{ARM926EJ-S=ARM926EJ-S-REV0
}
{ARM926EJ-S-MyVersion
IRamSize=0x8000
}
```

```
;End of Processors
```

This overrides the corresponding line in `armulate.dsc`.

Any details that are not specified in your file remain unaltered from what is specified in `armulate.dsc`.

## 4.15 ToolConf

This section contains the following subsections:

- *Toolconf overview*
- *File format* on page 4-69
- *Boolean flags in a ToolConf database* on page 4-71
- *SI units in a ToolConf database* on page 4-72
- *ToolConf\_Lookup* on page 4-73
- *ToolConf\_Cmp* on page 4-74.

### 4.15.1 Toolconf overview

ToolConf is a module within ARMulator. A ToolConf file is a tree-structured database consisting of tag and value pairs. Tags and values are strings, and are usually case-insensitive. ToolConf files are files of type .ami or .dsc.

You can find a value associated with a tag from a ToolConf database, or add or change a value.

If a tag is given a value more than once, the first value is used.



### 4.15.2 File format

The following are typical ToolConf database lines:

```
TagA=ValueA
TagA=NewValue
Othertag
Othertag=Othervalue
;; Lines starting with ; (semicolon) are comments.
; Tag=Value
```

The first line creates a tag in the ToolConf called TagA, with value ValueA.

The second line has no effect, as TagA already has a value.

The third line creates a tag called Othertag, with no value.

The fourth line gives the value Othervalue to Othertag.

There must be no whitespace at the beginning of database lines, in tags, in values, or between tags or values and the = symbol.

Conventionally, ordinary comments start with two semicolons. Lines starting with one semicolon are usually commented-out lines. You can comment out a line to disable it, or uncomment a commented-out line to enable it.

A comment must be on a line by itself.

#### File header

If you add any ToolConf files, the first line of the file must be:

```
;; ARMulator configuration file type 3
```

ARMulator ignores any .ami or .dsc files that do not begin with this header.

#### Tree structure

Each tag can have another ToolConf database associated with it, called its child. When a tag lookup is performed on a child, if the tag is not found in the child, the search continues in the parent, and if necessary in the parent's parent and so on until the tag is found.

This means that the child only includes tags whose values are different from those of the same tag in the parent.

If child databases are specified more than once for the same parent, the child databases are merged.

## Specifying children

There are two ways of specifying children in a ToolConf database.

One is more suited to specifying large children:

```
{ TagP=ValueP
  TagC1=ValueC1
  TagC2=ValueC2
}
```

This creates a tag called TagP, with the value ValueP, and a child database. Two tags are given values in the child.

The other is more suited to specifying small children:

```
TagP:TagC=ValueC
```

This creates a tag called TagP, with no value. TagP has a child in which one tag is created, TagC, with value ValueC. It is equivalent to:

```
{ TagP
  TagC=ValueC
}
```

## Conditional expressions

The full `#if...#elif...#else...#endif` syntax is supported. You can use this to skip regions of a ToolConf database. Expressions use tags from the file, for example, the C preprocessor sequence:

```
#define Control True

#if defined(Control) && Control==True
#define controlIsTrue Yes
#endif
```

maps to the ToolConf sequence:

```
Control=True

#if Control && Control=True
ControlIsTrue=Yes
#endif
```

A condition is evaluated from left to right, on the contents of the configuration at that point. Table 4-8 shows the operators that can be used in ToolConf conditional expressions.

**Table 4-8 Operators in ToolConf preprocessor expressions**

Operator	Example	Description
<i>none</i>	Tag	Test for existence of tag definition
==	Tag==Value	Case-insensitive string equality test
!=	Tag!=Value	Case-insensitive string inequality test
(...)	(Tag==Value)	Grouping
&&	TagA==ValueA && TagB==ValueB	Boolean AND
	TagA==ValueA    TagB==ValueB	Boolean OR
!	!(Tag==Value)	Boolean NOT

### File inclusion

You can use the `#include` directive to include one ToolConf file in another. The directive is ignored if it is in a region which is being skipped under control of a conditional expression.

#### 4.15.3 Boolean flags in a ToolConf database

Table 4-9 shows the full set of permissible values for Boolean flags. The strings are case-insensitive.

**Table 4-9 Boolean values**

True	False
True	False
On	Off
High	Low
Hi	Lo
1	0
T	F

#### 4.15.4 SI units in a ToolConf database

Some values can be specified using SI (Système Internationale) units, for example:

```
ClockSpeed=10MHz  
MemorySize=2Gb
```

The scaling factor is set by the prefix to the unit. ARMulator only accepts k, M, or G prefixes for kilo, mega, and giga. These correspond to scalings of  $10^3$ ,  $10^6$ , and  $10^9$ , or  $2^{10}$ ,  $2^{20}$ , and  $2^{30}$ . ARMulator decides which scaling to use according to context.

### 4.15.5 ToolConf\_Lookup

This function performs a lookup on a specified tag in an .ami or .dsc file. If the tag is found, its associated value is returned. Otherwise, NULL is returned.

#### Syntax

```
const char *ToolConf_Lookup(toolconf hashv, tag_t tag)
```

where:

*hashv* is the database to perform the lookup on.

*tag* is the tag to search for in the database. The tag is case-dependent.

#### Return

The function returns:

- a **const** pointer to the tag value, if the search is successful
- NULL, if the search is not successful.

#### Example

```
const char *option = ToolConf_Lookup(db, ARMu1Cnf_Size);  
  
/* ARMu1Cnf_Size is defined in armcnf.h */
```

### 4.15.6 ToolConf\_Cmp

This function performs a case-insensitive comparison of two ToolConf database tag values.

#### Syntax

```
int ToolConf_Cmp(const char *s1, const char *s2)
```

where:

*s1* is a pointer to the first string value to compare.

*s2* is a pointer to the second string value to compare.

#### Return

The function returns:

- 1, if the strings are identical
- 0, if the strings are different.

#### Example

```
if (ToolConf_Cmp(option, "8192"))
```

## 4.16 Reference peripherals

Two reference peripherals are detailed here:

- *Interrupt controller*
- *Timer* on page 4-77.

### 4.16.1 Interrupt controller

The base address of the interrupt controller, IntBase, is configurable (see *Interrupt controller* on page 2-33).

Table 4-10 shows the location of individual registers.

**Table 4-10 Interrupt controller memory map**

Address	Read	Write
IntBase	IRQStatus	Reserved
IntBase + 004	IRQRawStatus	Reserved
IntBase + 008	IRQEnable	IRQEnableSet
IntBase + 00C	Reserved	IRQEnableClear
IntBase + 010	Reserved	IRQSoft
IntBase + 100	FIQStatus	Reserved
IntBase + 104	FIQRawStatus	Reserved
IntBase + 108	FIQEnable	FIQEnableSet
IntBase + 10C	Reserved	FIQEnableClear

**Interrupt controller defined bits**

The FIQ interrupt controller is one bit wide. It is located on bit 0.

Table 4-11 gives details of the interrupt sources associated with bits 1 to 5 in the IRQ interrupt controller registers. You can use bit 0 for a duplicate FIQ input.

**Table 4-11 Interrupt sources**

Bit	Interrupt source
0	FIQ source
1	Programmed interrupt
2	Communications channel Rx
3	Communications channel Tx
4	Timer 1
5	Timer 2

**Note**

Timer 1 and Timer 2 can be configured to use different bits in the IRQ controller registers, see *Timer* on page 2-34.



## 4.16.2 Timer

The base address of the timer, *TimerBase*, is configurable (see *Timer* on page 2-34).

See Table 4-12 for the location of individual registers.

**Table 4-12 Timer memory map**

Address	Read	Write
TimerBase	Timer1Load	Timer1Load
TimerBase + 04	Timer1Value	Reserved
TimerBase + 08	Timer1Control	Timer1Control
TimerBase + 0C	Reserved	Timer1Clear
TimerBase + 10	Reserved	Reserved
TimerBase + 20	Timer2Load	Timer2Load
TimerBase + 24	Timer2Value	Reserved
TimerBase + 28	Timer2Control	Timer2Control
TimerBase + 2C	Reserved	Timer2Clear
TimerBase + 30	Reserved	Reserved

### Timer load registers

Write a value to one of these registers to set the initial value of the corresponding timer counter. You must write the top 16 bits as zeroes.

If the timer is in periodic mode, this value is also reloaded to the timer counter when the counter reaches zero.

If you read from this register, the bottom 16 bits return the value that you wrote. The top 16 bits are undefined.

### Timer value registers

Timer value registers are read-only. The bottom 16 bits give the current value of the timer counter. The top 16 bits are undefined.

Timer clear registers

Timer clear registers are write-only. Writing to one of them clears an interrupt generated by the corresponding timer.

Timer control registers

See Table 4-14 and Table 4-13 for details of timer register bits. Only bits 7, 6, 3, and 2 are used. You must write all others as zeroes.

Table 4-13 Clock prescaling using bits 2 and 3

Bit 3	Bit 2	Clock divided by	Stages of prescale
0	0	1	0
0	1	16	4
1	0	256	8
1	1	Undefined	-

The counter counts downwards. It counts **BCLK** cycles, or **BCLK** cycles divided by 16 or 256. Bits 2 and 3 define the prescaling applied to the clock.

Table 4-14 Timer enable and mode control using bits 6 and 7

	0	1
Bit 7	Timer disabled	Timer enabled
Bit 6	Free-running mode	Periodic mode

In free-running mode, the timer counter overflows when it reaches zero, and continues to count down from 0xFFFF.

In periodic mode, the timer generates an interrupt when the counter reaches zero. It then reloads the value from the load register and continues to count down from this value.

# Chapter 5

## Semihosting

This chapter describes the semihosting mechanism. Semihosting provides code running on an ARM target use of facilities on a host computer that is running an ARM debugger. Examples of such facilities include the keyboard input, screen output, and disk I/O. This chapter contains the following sections:

- *Semihosting* on page 5-2
- *Semihosting implementation* on page 5-5
- *Adding an application SWI handler* on page 5-8
- *Semihosting SWIs* on page 5-11
- *Debug agent interaction SWIs* on page 5-27.

## 5.1 Semihosting


Semihosting is a mechanism for ARM targets to communicate input/output requests from application code to a host computer running a debugger. This mechanism could be used, for example, to allow functions in the C library, such as `printf()` and `scanf()`, to use the screen and keyboard of the host rather than having a screen and keyboard on the target system.

This is useful because development hardware often does not have all the input and output facilities of the final system. Semihosting allows the host computer to provide these facilities.

Semihosting is implemented by a set of defined *software interrupt* (SWI) operations. The application invokes the appropriate SWI and the debug agent then handles the SWI exception. The debug agent provides the required communication with the host.

In many cases, the semihosting SWI will be invoked by code within library functions. The application can also invoke the semihosting SWI directly. Refer to the C library descriptions in the *ADS Compilers and Libraries Guide* for more information on support for semihosting in the ARM C library.

Figure 5-1 shows an overview of semihosting.



**Figure 5-1 Semihosting overview**

The semihosting SWI interface is common across all debug agents provided by ARM. Semihosted operations will work under ARMulator, RealMonitor, Angel, or Multi-ICE without any requirement for porting.

For further information on semihosting and the C libraries, see the *C and C++ Libraries* chapter in *ADS Compilers and Libraries Guide*. See also the *Writing Code for ROM* chapter in *ADS Developer Guide*.

### 5.1.1 The SWI interface

The ARM and Thumb SWI instructions contain a field that encodes the SWI number used by the application code. This number can be decoded by the SWI handler in the system. See the chapter on exception handling in *ADS Developer Guide* for more information on SWI handlers.

Semihosting operations are requested using a single SWI number. This leaves the other SWI numbers available for use by the application or operating system. The SWI used for semihosting is:

0x123456	in ARM state
0xAB	in Thumb state

The SWI number indicates to the debug agent that the SWI is a semihosting request. In order to distinguish between operations, the operation type is passed in r0. All other parameters are passed in a block that is pointed to by r1.

The result is returned in r0, either as an explicit return value or as a pointer to a data block. Even if no result is returned, assume that r0 is corrupted.

The available semihosting operation numbers passed in r0 are allocated as follows:

0x00 to 0x31	These are used by ARM.
0x32 to 0xFF	These are reserved for future use by ARM.
0x100 to 0x1FF	These are reserved for user applications. They will not be used by ARM.
	If you are writing your own SWI operations, however, you are advised to use a different SWI number rather than using the semihosted SWI number and these operation type numbers.
0x200 to 0xFFFFFFFF	These are undefined. They are not currently used and not recommended for use.

In the following sections, the number in parentheses after the operation name is the value placed into r0. For example SYS\_OPEN (0x01).

If you are calling SWIs from assembly language code it is best to use the operation names that are defined in `semihost.h`. You can define the operation names with an `EQU` directive. For example:

```
SYS_OPEN    EQU 0x01
SYS_CLOSE   EQU 0x02
```

### Changing the semihosting SWI numbers

It is strongly recommended that you do not change the semihosting SWI numbers `0x123456` (ARM) or `0xAB` (Thumb). If you do so you must:

- change all the code in your system, including library code, to use the new SWI number
- reconfigure your debugger to use the new SWI number.

## 5.2 Semihosting implementation

The functionality provided by semihosting is basically the same on all debug hosts. The implementation of semihosting, however, differs between hosts.

### 5.2.1 ARMulator

When a semihosting SWI is encountered, ARMulator traps the SWI directly and the instruction in the SWI entry in the vector table is not executed.

To turn the support for semihosting off in ARMulator, change `Default_Semihost` in the `default.ami` file to `No_Semihost`.

See *Peripheral models* on page 2-32 for more details.

### 5.2.2 RealMonitor

RealMonitor implements a SWI handler that must be integrated with your system to enable semihosting support.

When the target executes a semihosted SWI instruction, the RealMonitor SWI handler carries out the required communication with the host.

For further information refer to the documentation supplied with RealMonitor.

### 5.2.3 Angel

The Angel debug monitor installs a SWI handler during its initialization. This occurs when the target powers up.

When the target executes a semihosted SWI instruction, the Angel SWI handler carries out the required communication with the host.

## 5.2.4 Multi-ICE

When using Multi-ICE in default configuration, semihosting is implemented as follows:

1. On ARM7 processors:
  - a. A breakpoint is set on the SWI vector.
  - b. When this breakpoint is hit, Multi-ICE examines the SWI number.
  - c. If the SWI is recognized as a semihosting SWI, Multi-ICE emulates it and transparently restarts execution of the application.  
If the SWI is not recognized as a semihosting SWI, Multi-ICE halts the processor and reports an error.
2. On other processors:
  - a. Vector-catch logic traps SWIs.
  - b. If the SWI is recognized as a semihosting SWI, Multi-ICE emulates it and transparently restarts execution of the application.  
If the SWI is not recognized as a semihosting SWI, Multi-ICE halts the processor and reports an error.

This semihosting mechanism can be disabled or changed by the following debugger internal variables:

### `$semihosting_enabled`

Set this variable to 0 to disable semihosting. If you are debugging an application running from ROM, this allows you to use an additional watchpoint unit.

Set this variable to 1 to enable semihosting. This is the default.

Set this variable to 2 to enable Debug Communications Channel semihosting.

The S bit in `$vector_catch` has no effect unless semihosting is disabled.

### `$semihosting_vector`

This variable controls the location of the breakpoint set by Multi-ICE to detect a semihosted SWI. It is set to the SWI entry in the exception vector table (0x8) by default.

If your application requires semihosting as well as having its own SWI handler, set `$semihosting_vector` to an address in your SWI handler. This address must point to an instruction that is only executed if your SWI handler has identified a call to a semihosting SWI. All registers must already have been restored to whatever values they had on entry to your SWI handler.



Multi-ICE handles the semihosted SWI and then examines the contents of `lr` and returns to the instruction following the SWI instruction in your code.

Regardless of the value of `$vector_catch`, all exceptions and interrupts are trapped and reported as an error condition.

For details of how to modify debugger internal variables, see the appropriate debugger documentation.

### 5.2.5 Multi-ICE DCC semihosting

Multi-ICE can also use the debug communications channel so that the core is not stopped while semihosting takes place. This is enabled by setting `$semihosting_enabled` to 2. Refer to the *Multi-ICE User Guide* for more details.

## 5.3 Adding an application SWI handler

It can be useful to have both the semihosted SWIs and your own application-specific SWIs available. In such cases you must ensure that the two SWI mechanisms cooperate correctly. The way to ensure this depends upon the debug agent in use.

### 5.3.1 ARMulator

To get your own handler and the semihosting handler to cooperate, simply install your SWI handler into the SWI entry in the vector table. No other actions are required.

When an appropriate SWI is reached in your code, ARMulator detects that it is not a semihosting SWI and executes the instruction in the SWI entry of the vector table instead. This instruction must branch to your own SWI handler.

### 5.3.2 RealMonitor

The RealMonitor SWI handler must be integrated with your application to enable semihosting (see the documentation supplied with RealMonitor).

### 5.3.3 Angel

Application SWI handlers are added by:

1. Saving the SWI vector (as installed by Angel).
2. Adjusting the contents of the SWI vector to point to the application SWI handler. (This is called *chaining*.) This is described in more detail in the exception handling section of the *ADS Developer Guide*.

### 5.3.4 Multi-ICE

To ensure that the application SWI handler will successfully cooperate with Multi-ICE semihosting mechanism:

1. Install the application SWI handler into the vector table.
2. Modify `$semihosting_vector` to point to a location at the end of the application handler. This point in the handler must only be reached if your handler does not handle the SWI.

Before Multi-ICE traps the SWI, your SWI handler must restore all registers to the values they had when your SWI handler was entered. Typically, this means that your SWI handler must store the registers to a stack on entry and restore them before falling through to the semihosting vector address.

---

**Caution**


---

It is essential that the actual position \$semihosting\_vector points to within the application handler is correct.

---

See exception handling in the *ADS Developer Guide* for writing SWI handlers.

The following example SWI handler can detect if it fails to handle a SWI. In this case, it branches to an error handler:

```
; r0 = 1 if SWI handled
  CMP r0, #1           ; Test if SWI has been handled.
  BNE NoSuchSWI        ; Call unknown SWI handler.
  LDMFD sp!, {r0}       ; Unstack SPSR...
  MSR spsr_cxsf, r0     ; ...and restore it.
  LDMFD sp!, {r0-r12,pc}^ ; Restore registers and return.
```

This code could be modified to co-operate with Multi-ICE semihosting as follows:

```
; r0 = 1 if SWI handled
  CMP r0, #1           ; Test if SWI has been handled.
  LDMFD sp!, {r0}       ; Unstack SPSR...
  MSR spsr_cxsf, r0     ; ...and restore it.
  LDMFD sp!, {r0-r12,lr} ; Restore registers.
  MOVEQS pc, lr         ; Return if SWI handled.
Semi_SWI
  MOVS pc,lr            ; Fall through to Multi-ICE
                       ; interface handler.
```

The \$semihosting\_vector variable must be set up to point to the address of Semi\_SWI. The instruction at Semi\_SWI never gets executed because Multi-ICE returns directly to the application after processing the semihosted SWI (see Figure 5-2 on page 5-10).

---

**Caution**


---

Using a normal SWI return instruction ensures that the application does not crash if the semihosting breakpoint is not set up. The semihosting action requested is not carried out and the handler simply returns.

You must also be careful if you modify \$semihosting\_vector to point to the fall-through part of the application SWI handler. If \$semihosting\_vector changes value before the application starts execution, and semihosted SWIs are invoked before the application SWI handler is installed, an unknown watchpoint error will occur.

---




Figure 5-2 Semihosting with breakpoint

The error occurs because the vector table location for the SWI has not yet had the application handler installed into it and might still contain the software breakpoint bit pattern. Because the `$semihosting_vector` address has moved to a place that cannot currently be reached, Multi-ICE no longer knows about the triggered breakpoint. To prevent this from happening, you must change the contents of `$semihosting_vector` only at the point in your code where the application SWI handler is installed into the vector table.

**Note**

If semihosting is not required at all by an application, this process can be simplified by setting `$semihosting_enabled` to 0.

5.3.5 Multi-ICE DCC semihosting

When using the DCC semihosting mechanism, adding an application SWI handler must be done in exactly the same way as non-DCC semihosting (see *Multi-ICE* on page 5-8).

## 5.4 Semihosting SWIs

The SWIs listed in Table 5-1 implement the semihosted operations. These operations are used by C library functions such as `printf()` and `scanf()`. They can be treated as ATPCS function calls. However, except for `r0` that contains the return status, they restore the registers they are called with before returning.

Some targets provide additional semihosting calls. See the *ARM Firmware Suite* (AFS) documentation for details of SWIs provided by AFS.

**Table 5-1 Semihosting SWIs**

SWI	Description
<i>SYS_OPEN</i> (0x01) on page 5-12	Open a file on the host
<i>SYS_CLOSE</i> (0x02) on page 5-14	Close a file on the host
<i>SYS_WRITEC</i> (0x03) on page 5-14	Write a character to the console
<i>SYS_WRITE0</i> (0x04) on page 5-14	Write a null-terminated string to the console
<i>SYS_WRITE</i> (0x05) on page 5-15	Write to a file on the host
<i>SYS_READ</i> (0x06) on page 5-16	Read the contents of a file into a buffer
<i>SYS_READC</i> (0x07) on page 5-17	Read a byte from the console
<i>SYS_ISERROR</i> (0x08) on page 5-17	Determine if a return code is an error
<i>SYS_ISTTY</i> (0x09) on page 5-18	Check whether a file is connected to an interactive device
<i>SYS_SEEK</i> (0x0A) on page 5-18	Seek to a position in a file
<i>SYS_FLEN</i> (0x0C) on page 5-19	Return the length of a file
<i>SYS_TMPNAM</i> (0x0D) on page 5-19	Return a temporary name for a file
<i>SYS_REMOVE</i> (0x0E) on page 5-20	Remove a file from the host
<i>SYS_RENAME</i> (0x0F) on page 5-20	Rename a file on the host
<i>SYS_CLOCK</i> (0x10) on page 5-21	Number of centiseconds since execution started
<i>SYS_TIME</i> (0x11) on page 5-21	Number of seconds since January 1, 1970
<i>SYS_SYSTEM</i> (0x12) on page 5-22	Pass a command to the host command-line interpreter
<i>SYS_ERRNO</i> (0x13) on page 5-23	Get the value of the C library <code>errno</code> variable
<i>SYS_GET_CMDLINE</i> (0x15) on page 5-24	Get the command-line used to call the executable

Table 5-1 Semihosting SWIs (continued)

SWI	Description
<i>SYS_HEAPINFO</i> (0x16) on page 5-25	Get the system heap parameters
<i>SYS_ELAPSED</i> (0x30) on page 5-26	Get the number of target ticks since execution started
<i>SYS_TICKFREQ</i> (0x31) on page 5-26	Determine the tick frequency

———— **Note** —————

When used with Angel, these SWIs use the serializer and the global register block, and they can take a significant length of time to process.

5.4.1    **SYS\_OPEN (0x01)**

Open a file on the host system. The file path is specified either as relative to the current directory of the host process, or absolutely, using the path conventions of the host operating system.

The ARM targets interpret the special path name :tt as meaning the console input stream (for an open-read) or the console output stream (for an open-write). Opening these streams is performed as part of the standard startup code for those applications that reference the C stdio streams.

**Entry**

On entry, r1 contains a pointer to a three-word argument block:

- word 1**      This is a pointer to a null-terminated string containing a file or device name.
- word 2**      This is an integer that specifies the file opening mode. Table 5-2 gives the valid values for the integer, and their corresponding ANSI C fopen() mode.
- word 3**      This is an integer that gives the length of the string pointed to by word 1. The length does not include the terminating null character that must be present.

Table 5-2 Value of mode

mode	0	1	2	3	4	5	6	7	8	9	10	11
ANSI C fopen mode	r	rb	r+	r+b	w	wb	w+	w+b	a	ab	a+	a+b

## Return

On exit, r0 contains:

- a nonzero handle if the call is successful
- -1 if the call is not successful.

### 5.4.2 SYS\_CLOSE (0x02)

Closes a file on the host system. The handle must reference a file that was opened with SYS\_OPEN.

#### Entry

On entry, r1 contains a pointer to a one-word argument block:

**word 1**        This is a file handle referring to an open file.

#### Return

On exit, r0 contains:

- 0 if the call is successful
- -1 if the call is not successful.

### 5.4.3 SYS\_WRITEC (0x03)

Writes a character byte, pointed to by r1, to the debug channel. When executed under an ARM debugger, the character appears on the display device connected to the debugger.

#### Entry

On entry, r1 contains a pointer to the character.

#### Return

None. Register r0 is corrupted.

### 5.4.4 SYS\_WRITE0 (0x04)

Writes a null-terminated string to the debug channel. When executed under an ARM debugger, the characters appear on the display device connected to the debugger.

#### Entry

On entry, r1 contains a pointer to the first byte of the string.

#### Return

None. Register r0 is corrupted.



### 5.4.5 SYS\_WRITE (0x05)

Writes the contents of a buffer to a specified file at the current file position. The file position is specified either:

- explicitly, by a SYS\_SEEK
- implicitly as one byte beyond the previous SYS\_READ or SYS\_WRITE request.

The file position is at the start of the file when the file is opened, and is lost when the file is closed.

Perform the file operation as a single action whenever possible. For example, do not split a write of 16KB into four 4KB chunks unless there is no alternative.

#### Entry

On entry, r1 contains a pointer to a three-word data block:

- |               |  |
|---------------|--|
| <b>word 1</b> | This contains a handle for a file previously opened with SYS_OPEN            |
| <b>word 2</b> | This points to the memory containing the data to be written                  |
| <b>word 3</b> | This contains the number of bytes to be written from the buffer to the file. |

#### Return

On exit, r0 contains:

- 0 if the call is successful
- the number of bytes that are not written, if there is an error.

### 5.4.6 SYS\_READ (0x06)

Reads the contents of a file into a buffer. The file position is specified either:

- explicitly by a SYS\_SEEK
- implicitly one byte beyond the previous SYS\_READ or SYS\_WRITE request.

The file position is at the start of the file when the file is opened, and is lost when the file is closed. Perform the file operation as a single action whenever possible. For example, do not split a read of 16KB into four 4KB chunks unless there is no alternative.

#### Entry

On entry, r1 contains a pointer to a four-word data block:

**word 1** This contains a handle for a file previously opened with SYS\_OPEN.

**word 2** This points to a buffer.

**word 3** This contains the number of bytes to read to the buffer from the file.

#### Return

On exit:

- r0 contains zero if the call is successful.
- If r0 contains the same value as word 3, the call has failed and end-of-file is assumed.
- If r0 contains a greater value than word 3, the call was partially successful. No error is assumed, but the buffer has not been filled.

If the handle is for an interactive device (that is, SYS\_ISTTY returns –1 for this handle), a nonzero return from SYS\_READ indicates that the line read did not fill the buffer.

### 5.4.7 SYS\_READC (0x07)

Reads a byte from the console.

#### Entry

Register r1 must contain zero. There are no other parameters or values possible.

#### Return

On exit, r0 contains the byte read from the console.

### 5.4.8 SYS\_ISERROR (0x08)

Determines whether the return code from another semihosting call is an error status or not. This call is passed a parameter block containing the error code to examine.

#### Entry

On entry, r1 contains a pointer to a one-word data block:

**word 1**        This is the required status word to check.

#### Return

On exit, r0 contains:

- 0 if the status word is not an error indication
- a nonzero value if the status word is an error indication.

### 5.4.9 SYS\_ISTTY (0x09)

Checks whether a file is connected to an interactive device.

#### Entry

On entry, r1 contains a pointer to a one-word argument block:

**word 1** This is a handle for a previously opened file object.

#### Return

On exit, r0 contains:

- 1 if the handle identifies an interactive device
- 0 if the handle identifies a file
- a value other than 1 or 0 if an error occurs.

### 5.4.10 SYS\_SEEK (0x0A)

Seeks to a specified position in a file using an offset specified from the start of the file. The file is assumed to be a byte array and the offset is given in bytes.

#### Entry

On entry, r1 contains a pointer to a two-word data block:

**word 1** This is a handle for a seekable file object.

**word 2** This is the absolute byte position to be sought to.

#### Return

On exit, r0 contains:

- 0 if the request is successful
- A negative value if the request is not successful. SYS\_ERRNO can be used to read the value of the host errno variable describing the error.

---

#### Note

The effect of seeking outside the current extent of the file object is undefined.

---

### 5.4.11 SYS\_FLEN (0x0C)

Returns the length of a specified file.

#### Entry

On entry, r1 contains a pointer to a one-word argument block:

**word 1**        This is a handle for a previously opened, seekable file object.

#### Return

On exit, r0 contains:

- the current length of the file object, if the call is successful
- -1 if an error occurs.

### 5.4.12 SYS\_TMPNAM (0x0D)

Returns a temporary name for a file identified by a system file identifier.

#### Entry

On entry, r1 contains a pointer to a three-word argument block:

**word 1**        This is a pointer to a buffer.

**word 2**        This is a target identifier for this filename. Its value must be an integer in the range 0 to 255.

**word 3**        This contains the length of the buffer. The length must be at least the value of L\_tmpnam on the host system.

#### Return

On exit, r0 contains:

- 0 if the call is successful
- -1 if an error occurs.

The buffer pointed to by r1 contains the filename, prefixed with a suitable directory name.

If you use the same target identifier again, the same filename is returned.

### 5.4.13 SYS\_REMOVE (0x0E)

---

**Caution**


---

Deletes a specified file on the host filing system.

---

**Entry**

On entry, r1 contains a pointer to a two-word argument block:

- |               |  |
|---------------|--|
| <b>word 1</b> | This points to a null-terminated string that gives the pathname of the file to be deleted. |
| <b>word 2</b> | This is the length of the string.  |

**Return**

On exit, r0 contains:

- 0 if the delete is successful
- a nonzero, host-specific error code if the delete fails.

### 5.4.14 SYS\_RENAME (0x0F)

Renames a specified file.

**Entry**

On entry, r1 contains a pointer to a four-word data block:

- |               |  |
|---------------|--|
| <b>word 1</b> | This is a pointer to the name of the old file. |
| <b>word 2</b> | This is the length of the old file name.       |
| <b>word 3</b> | This is a pointer to the new file name.        |
| <b>word 4</b> | This is the length of the new file name.       |

Both strings are null-terminated.

**Return**

On exit, r0 contains:

- 0 if the rename is successful
- a nonzero, host-specific error code if the rename fails.

### 5.4.15 SYS\_CLOCK (0x10)

Returns the number of centiseconds since the execution started.

Values returned by this SWI can be of limited use for some benchmarking purposes because of communication overhead or other agent-specific factors. For example, with Multi-ICE the request is passed back to the host for execution. This can lead to unpredictable delays in transmission and process scheduling.

Use this function to calculate time intervals (the length of time some action took) by calculating differences between intervals with and without the code sequence to be timed

Some systems allow more accurate timing (see *SYS\_ELAPSED (0x30)* on page 5-26 and *SYS\_TICKFREQ (0x31)* on page 5-26).

#### Entry

Register r1 must contain zero. There are no other parameters.

#### Return

On exit, r0 contains:

- the number of centiseconds since some arbitrary start point, if the call is successful
- -1 if the call is unsuccessful (for example, because of a communications error).

### 5.4.16 SYS\_TIME (0x11)

Returns the number of seconds since 00:00 January 1, 1970. This is real-world time, regardless of any ARMulator configuration.

#### Entry

There are no parameters.

#### Return

On exit, r0 contains the number of seconds.

### 5.4.17 SYS\_SYSTEM (0x12)

Passes a command to the host command-line interpreter. This enables you to execute a system command such as `dir`, `ls`, or `pwd`. The terminal I/O is on the host, and is not visible to the target.

———— **Caution** ————

The command passed to the host is actually executed on the host. Ensure that any command passed will have no unintended consequences.

---

#### Entry

On entry, `r1` contains a pointer to a two-word argument block:

- |               |  |
|---------------|--|
| <b>word 1</b> | This points to a string that is to be passed to the host command-line interpreter. |
| <b>word 2</b> | This is the length of the string.  |

#### Return

On exit, `r0` contains the return status.



### 5.4.18 SYS\_ERRNO (0x13)

Returns the value of the C library `errno` variable associated with the host implementation of the semihosting SWIs. The `errno` variable can be set by a number of C library semihosted functions, including:

- `SYS_REMOVE`
- `SYS_OPEN`
- `SYS_CLOSE`
- `SYS_READ`
- `SYS_WRITE`
- `SYS_SEEK`.

Whether `errno` is set or not, and to what value, is entirely host-specific, except where the ANSI C standard defines the behavior.

#### Entry

There are no parameters. Register `r1` must be zero.

#### Return

On exit, `r0` contains the value of the C library `errno` variable.

### 5.4.19 SYS\_GET\_CMDLINE (0x15)

Returns the command line used to call the executable.

#### Entry

On entry, r1 points to a two-word data block to be used for returning the command string and its length:

- word 1** This is a pointer to a buffer of at least the size specified in word two.  
**word 2** This is the length of the buffer in bytes.

#### Return

On exit:

- Register r1 points to a two-word data block:
  - word 1** This is a pointer to null-terminated string of the command line.
  - word 2** This is the length of the string.

The debug agent might impose limits on the maximum length of the string that can be transferred. However, the agent must be able to transfer a command line of at least 80 bytes.

In the case of the Angel debug monitor using ADP, the maximum is slightly more than 200 characters.
- Register r0 contains an error code:
  - 0 if the call is successful
  - -1 if the call is unsuccessful (for example, because of a communications error).

## 5.4.20 SYS\_HEAPINFO (0x16)

Returns the system stack and heap parameters. The values returned are typically those used by the C library during initialization. For ARMulator, the values returned are the those provided in `peripherals.ami`. For Multi-ICE, the values returned are the image location and the top of memory.

The C library can override these values (see *ADS Compilers and Libraries Guide* for more information on memory management in the C library).

The host debugger determines the actual values to return by using the `$top_of_memory` debugger variable.

### Entry

On entry, `r1` contains the address of a pointer to a four-word data block. The contents of the data block are filled by the function. See Example 5-1 for the structure of the data block and return values.

### Example 5-1

```
struct block {
    int heap_base;
    int heap_limit;
    int stack_base;
    int stack_limit;
};
struct block *mem_block, info;
mem_block = &info;
AngelSWI(SYS_HEAPINFO, (unsigned) &mem_block);
```

### Note

If word one of the data block has the value zero, the C library replaces the zero with `Image$$ZI$$Limit`. This value corresponds to the top of the data region in the memory map.

### Return

On exit, `r1` contains the address of the pointer to the structure.

If one of the values in the structure is 0, the system was unable to calculate the real value.

### 5.4.21 SYS\_ELAPSED (0x30)

Returns the number of elapsed target ticks since the support code started execution. Use SYS\_TICKFREQ to determine the tick frequency.

#### Entry

On entry, r1 points to a two-word data block to be used for returning the number of elapsed ticks:

- word 1**        The least significant word in the doubleword value.
- word 2**        The most significant word.

#### Return

On exit, :

- r0 contains –1 if r1 does point to a doubleword containing the number of elapsed ticks. Multi-ICE does not support this SWI and always returns –1 in r0.
- r1 points to a doubleword (low-order word first) that contains the number of elapsed ticks.

### 5.4.22 SYS\_TICKFREQ (0x31)

Returns the tick frequency.

#### Entry

Register r1 must contain 0 on entry to this routine.

#### Return

On exit, r0 contains either:

- the number ticks per second
- –1 if the target does not know the value of one tick. Multi-ICE does not support this SWI and always returns –1.

## 5.5 Debug agent interaction SWIs

In addition to the C library semihosted functions described in *Semihosting SWIs* on page 5-11, the following SWIs support interaction with the debug agent:

- The ReportException SWI. This SWI is used by the semihosting support code as a way to report an exception to the debugger.
- The EnterSVC SWI. This SWI sets the processor to Supervisor mode.
- The reason\_LateStartup SWI. This SWI is obsolete and no longer supported.

These are described below.

### 5.5.1 angel\_SWIreason\_EnterSVC (0x17)

Sets the processor to Supervisor (SVC) mode and disables all interrupts by setting both interrupt mask bits in the new CPSR. With RealMonitor, Angel, or Multi-ICE, the User stack pointer (r13\_USR) is copied to the Supervisor stack pointer (r13\_SVC) and the I and F bits in the current CPSR are set, disabling normal and fast interrupts.

#### ————— Note —————

If debugging with ARMulator:

- r0 is set to zero indicating that no function is available for returning to User mode
- the User mode stack pointer is *not* copied to the Supervisor stack pointer.

#### Entry

Register r1 is not used. The CPSR can specify User or Supervisor mode.

#### Return

On exit, r0 contains the address of a function to be called to return to User mode. The function has the following prototype:

```
void ReturnToUSR(void)
```

If EnterSVC is called in User mode, this routine returns the caller to User mode and restores the interrupt flags. Otherwise, the action of this routine is undefined.

If entered in User mode, the Supervisor stack is lost as a result of copying the user stack pointer. The return to User routine restores r13\_SVC to the Angel Supervisor mode stack value, but this stack must not be used by applications.

After executing the SWI, the current link register will be r14\_SVC, not r14\_USR. If the value of r14\_USR is required after the call, it must be pushed onto the stack before the call and popped afterwards, as for a BL function call.

### 5.5.2 angel\_SWIreason\_ReportException (0x18)

This SWI can be called by an application to report an exception to the debugger directly. The most common use is to report that execution has completed, using ADP\_Stopped\_ApplicationExit.

#### Entry

On entry r1 is set to one of the values listed in Table 5-3 and Table 5-4. These values are defined in adp.h.

The hardware exceptions are generated if the debugger variable \$vector\_catch is set to catch that exception type, and the debug agent is capable of reporting that exception type. Angel cannot report exceptions for interrupts on the vector it uses itself.

**Table 5-3 Hardware vector reason codes**

Name (#defined in adp.h)	Hexadecimal value
ADP_Stopped_BranchThroughZero	0x20000
ADP_Stopped_UndefinedInstr	0x20001
ADP_Stopped_SoftwareInterrupt	0x20002
ADP_Stopped_PrefetchAbort	0x20003
ADP_Stopped_DataAbort	0x20004
ADP_Stopped_AddressException	0x20005
ADP_Stopped_IRQ	0x20006
ADP_Stopped_FIQ	0x20007

Exception handlers can use these SWIs at the end of handler chains as the default action, to indicate that the exception has not been handled.

**Table 5-4 Software reason codes**

Name (#defined in adp.h)	Hexadecimal value
ADP_Stopped_BreakPoint	0x20020
ADP_Stopped_WatchPoint	0x20021
ADP_Stopped_StepComplete	0x20022

Table 5-4 Software reason codes (continued)

Name (#defined in adp.h)	Hexadecimal value
ADP_Stopped_RunTimeErrorUnknown	*0x20023
ADP_Stopped_InternalError	*0x20024
ADP_Stopped_UserInterruption	0x20025
ADP_Stopped_ApplicationExit	0x20026
ADP_Stopped_StackOverflow	*0x20027
ADP_Stopped_DivisionByZero	*0x20028
ADP_Stopped_OSSpecific	*0x20029

\* next to values in Table 5-4 on page 5-29 indicates that the value is not supported by the ARM debuggers. The debugger reports an Unhandled ADP\_Stopped exception for these values.

Return

No return is expected from these calls. However, it is possible for the debugger to request that the application continue by performing an RDI\_Execute request or equivalent. In this case, execution continues with the registers as they were on entry to the SWI, or as subsequently modified by the debugger.

5.5.3 angel\_SWIreason\_LateStartup (0x20)

This SWI is obsolete.



# Glossary

The items in this glossary are listed in alphabetical order, with any symbols and numerics appearing at the end.

**ADP** *See Angel Debug Protocol.*

**ADS** *See ARM Developer Suite.*

**Advanced Microcontroller Bus Architecture**

On-chip communications standard for high-performance 32-bit and 16-bit embedded microcontrollers.

**AMBA** *See Advanced Microcontroller Bus Architecture.*

**Angel** Angel is a program that enables you to develop and debug applications running on ARM-based hardware. Angel can debug applications running in either ARM state or Thumb state.

**Angel Debug Protocol** Angel uses a debugging protocol called the Angel Debug Protocol (ADP) to communicate between the host system and the target system. ADP supports multiple channels and provides an error-correcting communications protocol.

**ARM Developer Suite** A suite of applications, together with supporting documentation and examples, that enable you to write and debug applications for the ARM family of RISC processors.

**ARM eXtended Debugger**

The ARM eXtended Debugger (AXD) is the latest debugger software from ARM that enables you to make use of a debug agent in order to examine and control the execution of software running on a debug target. AXD is supplied in both Windows and UNIX versions.

**ARM Symbolic Debugger**

An interactive source-level debugger providing high-level debugging support for languages such as C, and low-level support for assembly language. It is a command-line debugger that runs on all supported platforms.

**armsd**

*See* ARM Symbolic Debugger.

**ARMulator**

ARMulator is an instruction set simulator. It is a collection of modules that simulate the instruction sets and architecture of various ARM processors.

**AXD**

*See* ARM eXtended Debugger.

**Big-endian**

Memory organization where the least significant byte of a word is at a higher address than the most significant byte. *See also* *Little-endian*.

**Breakpoint**

A location in the image. If execution reaches this location, the debugger halts execution of the image. *See also* *Watchpoint*.

**Coprocessor**

An additional processor which is used for certain operations. Usually used for floating-point math calculations, signal processing, or memory management.

**CPSR**

Current Program Status Register. *See* *Program Status Register*.

**Debugger**

An application that monitors and controls the execution of a second application. Usually used to find errors in the application program flow.

**Double word**

A 64-bit unit of information. Contents are taken as being an unsigned integer unless otherwise stated.

**Function**

A C++ method or free function.

**Halfword**

A 16-bit unit of information. Contents are taken as being an unsigned integer unless otherwise stated.

**Host**

A computer which provides data and other services to another computer.

**ICE**

In-Circuit Emulator.

**Image**

A file of executable code which can be loaded into memory on a target and executed by a processor there.

**Little-endian**

Memory organization where the least significant byte of a word is at a lower address than the most significant byte. *See also* *Big-endian*.

**Memory management unit**

Hardware that controls caches and access permissions to blocks of memory, and translates virtual to physical addresses.

**MMU**

See *Memory Management Unit*.

**Multi-ICE**

Multi-processor in-circuit emulator. ARM registered trademark.

**Processor**

An actual processor, real or emulated running on the target. A processor always has at least one context of execution.

**Processor Status Register**

See *Program Status Register*.

**Profiling**

Accumulation of statistics during execution of a program being debugged, to measure performance or to determine critical areas of code.

*Call-graph profiling* provides great detail but slows execution significantly. *Flat profiling* provides simpler statistics with less impact on execution speed.

For both types of profiling you can specify the time interval between statistics-collecting operations.

**Program Status Register**

*Program Status Register* (PSR), containing some information about the current program and some information about the current processor. Often, therefore, also referred to as *Processor Status Register*.

Is also referred to as *Current PSR* (CPSR), to emphasize the distinction between it and the *Saved PSR* (SPSR). The SPSR holds the value the PSR had when the current function was called, and which will be restored when control is returned.

**Protection Unit**

Hardware that controls caches and access permissions to blocks of memory.

**PSR**

See *Program Status Register*.

**PU**

See *Protection Unit*.

**RDI**

See *Remote Debug Interface*.

**Remote Debug Interface**

The Remote Debug Interface (RDI) is an ARM standard procedural interface between a debugger and the debug agent. RDI gives the debugger a uniform way to communicate with:

a debug agent running on the host (for example, ARMulator)

a debug monitor running on ARM-based hardware accessed through a communication link (for example, Angel)

a debug agent controlling an ARM processor through hardware debug support (for example, Multi-ICE).

**Saved Program Status Register**

*See* Program Status Register

**Semihosting**

A mechanism whereby the target communicates I/O requests made in the application code to the host system, rather than attempting to support the I/O itself.

**Software Interrupt**

SWI. An instruction that causes the processor to call a programmer-specified subroutine. Used by ARM to handle semihosting.

**Source File**

A file which is processed as part of the image building process. Source files are associated with images.

**SPSR**

Saved Program Status Register. *See* *Program Status Register*.

**SWI**

*See* Software Interrupt.

**Target**

The target processor (real or simulated), on which the target application is running.

The fundamental object in any debugging session. The basis of the debugging system. The environment in which the target software will run. It is essentially a collection of real or simulated processors.

**Tracing**

Recording diagnostic messages in a log file, to show the frequency and order of execution of parts of the image. The text strings recorded are those that you specify when defining a breakpoint or watchpoint. *See* *Breakpoint* and *Watchpoint*. *See also* *Stack backtracing*.

**Watchpoint**

A location in the image that is monitored. If the value stored there changes, the debugger halts execution of the image. *See also* *Breakpoint*.

**Word**

A 32-bit unit of information. Contents are taken as being an unsigned integer unless otherwise stated.

# Index

The items in this index are listed in alphabetical order, with symbols and numerics appearing at the end. The references given are to page numbers.

## A

- AddCounterDesc 4-46
- AddCounterValue 4-47, 4-48
- adp.h 5-29
- ADP\_Stopped\_ApplicationExit 5-29
- Angel
  - adding SWI handler 5-8
  - debug agent interaction SWIs 5-27
  - Enter SVC mode 5-27
  - Report Exception SWI 5-29
  - semihosting SWIs 5-11
- angel\_SWIreason\_EnterSVC 5-27
- angel\_SWIreason\_ReportException 5-29
- armflat.c ARMulator model 2-26
- armmap.c ARMulator model 2-27
- armsd.map 2-28
- ARMulator
  - accuracy 1-2, 2-2
  - armul.cnf 4-63
  - benchmarking 1-2, 2-2
  - callback 4-33
  - configurable memory model 2-27
  - configuring tracer 2-10, 2-13
  - counters 4-35
  - data abort 4-38
  - event scheduling 4-40
  - events 4-29
  - exceptions 4-26, 4-34
  - functions *See* Functions, ARMulator
  - initializing PU 2-20
  - interrupt controller 4-75
  - logging 4-35
  - map files 4-59
  - memory access 4-38
  - memory statistics 4-62
  - models *See* Models, ARMulator
  - overview 2-2
  - predefined tags 4-64
  - profiling 4-35
  - PU initialization 2-20
  - RDI logging level 2-5
  - reference peripherals 4-75
  - and remote debug interface 4-15
  - remote debug interface 4-35, 4-52
  - state 4-3
  - tags 4-2, 4-64
  - timer 4-77
  - ToolConf 4-2, 4-63, 4-68
  - trace file interpretation 2-6
  - tracing 4-35
  - upcalls *See* Upcalls, ARMulator
- armul.cnf 4-63
- ARM740T model, ARMulator 2-24
- ARM940T model, ARMulator 2-25
- arm.h 5-4

## C

- C library
  - errno 5-23
  - Semihosting SWIs 5-2
- Callback, ARMulator 4-33
- cdp, ARMulator function 4-23
- ConsolePrint 4-53, 4-54, 4-55
- Coprocessor
  - ARMulator model 4-15

Counters, ARMulator 4-35  
 CPRead, ARMulator function 4-10  
 CPWrite, ARMulator function 4-11

## D

Debug interaction SWIs 5-27  
 Debugger variables  
     \$memory\_statistics 4-62  
     \$memstate 2-27  
     \$statistics 2-27  
 DebugPause 4-16  
 DebugPrint 4-52  
 default.ami 2-4, 3-8

## E

EndCondition, ARMulator function 4-49  
 Endianness  
     bigend signal 4-33  
 errno, C library 5-23  
 Event scheduling, ARMulator 4-40  
 Events, ARMulator 4-29  
 EventUpcall, ARMulator 4-37  
 Exceptions  
     and debug agent 5-29  
     reporting in debug agent 5-29  
 Exceptions, ARMulator 4-26, 4-34  
 ExceptionUpcall, ARMulator 4-34

## F

Files  
     adp.h 5-29  
     arm.h 5-4  
 Functions, ARMulator  
     ARMulif\_EndCondition 4-49  
     ARMulif\_GetCoreClockFreq 4-50  
     ARMulif\_InstallHourglass 4-51  
     ARMulif\_RemoveHourglass 4-51  
     ARMulif\_StopExecution 4-49  
     ARMul\_AddCounterDesc 4-46  
     ARMul\_AddCounterValue 4-47, 4-48

ARMul\_ConsolePrint 4-53, 4-54, 4-55  
 ARMul\_CPRead 4-10  
 ARMul\_CPWrite 4-11  
 ARMul\_DebugPause 4-56  
 ARMul\_DebugPrint 4-52  
 ARMul\_GetCPSR 4-7  
 ARMul\_GetMode 4-9  
 ARMul\_GetPC 4-6  
 ARMul\_GetReg 4-5  
 ARMul\_GetR15 4-6  
 ARMul\_GetSPSR 4-8  
 ARMul\_PrettyPrint 4-53, 4-54, 4-55  
 ARMul\_RaiseError 4-45  
 ARMul\_RaiseEvent 4-32  
 ARMul\_ReadByte 4-38  
 ARMul\_ReadHalfWord 4-38  
 ARMul\_ReadWord 4-38  
 ARMul\_ScheduleEvent 4-40  
 ARMul\_SetCPSR 4-7  
 ARMul\_SetNfiq 4-26, 4-27  
 ARMul\_SetNirq 4-26, 4-27  
 ARMul\_SetPC 4-6  
 ARMul\_SetReg 4-5  
 ARMul\_SetR15 4-6  
 ARMul\_SetSPSR 4-8  
 ARMul\_ThumbBit 4-9  
 ARMul\_Time 4-45  
 ARMul\_WriteByte 4-39  
 ARMul\_WriteHalfWord 4-39  
 ARMul\_WriteWord 4-39  
 cdp 4-23  
 ldc 4-17  
 mcr 4-20, 4-21, 4-22  
 mrc 4-19  
 read 4-24  
 stc 4-18  
 ToolConf\_Cmp 4-74  
 ToolConf\_Lookup 4-73  
 write 4-25

## G

GetCoreClockFreq, ARMulator function 4-50  
 GetCPSR, ARMulator function 4-7  
 GetMode, ARMulator function 4-9

GetPC, ARMulator function 4-6  
 GetReg, ARMulator function 4-5  
 GetR15, ARMulator function 4-6  
 GetSPSR, ARMulator function 4-8  
 Glossary Glossary-1

## I

Input/Output  
     semihosting SWIs 5-11  
 InstallHourglass, ARMulator function 4-51  
 Interrupt controller 4-75

## L

ldc, ARMulator function 4-17  
 Logging level, RDI 2-5  
 Logging, ARMulator 4-35

## M

Map file, ARMulator 4-59  
 mcr, ARMulator function 4-20, 4-21, 4-22  
 Memory statistics, ARMulator 4-62  
 \$memory\_statistics 4-62  
 Models, ARMulator  
     bus cycle insertion 4-38  
     coprocessor 4-15  
     memory 4-38  
     pagetab.c 3-3  
     profiler.c 2-12, 3-3  
     stackuse.c 3-3  
     tracer.c 2-5, 3-3  
 mrc, ARMulator function 4-19  
 Multi-ICE and EmbeddedICE  
     DCC 5-10

## P

pagetab.c ARMulator model 3-3  
 peripherals.ami 2-4, 3-3, 3-8  
 PrettyPrint 4-53, 4-54, 4-55  
 profiler.c 4-35

profiler.c ARMulator model 2-12, 3-3  
 Protection unit 2-24, 2-25  
 PU initialization, ARMulator 2-20

## R

RaiseError 4-45  
 RaiseEvent 4-32  
 RDI logging level 2-5  
 ReadByte, ARMulator function 4-38  
 ReadHalfWord 4-38  
 ReadWord, ARMulator function 4-38  
 read, ARMulator function 4-24  
 Reference peripherals 4-75  
 Remote debug interface  
   and ARMulator 4-15  
   ARMulator 4-35, 4-52  
 RemoveHourglass, ARMulator  
   function 4-51  
 Reporting exceptions 5-29  
 Return codes, ARMulator functions  
   ARMul\_BUSY 4-17, 4-18, 4-19,  
     4-20, 4-21, 4-22, 4-23  
   ARMul\_CANT 4-17, 4-18, 4-19,  
     4-20, 4-21, 4-22, 4-23, 4-24, 4-25  
   ARMul\_DONE 4-17, 4-18, 4-19,  
     4-20, 4-21, 4-22, 4-23, 4-24, 4-25

## S

ScheduleEvent 4-40  
 Semihosting SWIs 5-11  
   adding to application 5-8  
   C library 5-2  
   implementation 5-5  
   interface 5-3  
   intro 5-1  
   SYS\_CLOCK 5-21  
   SYS\_CLOSE 5-14  
   SYS\_ELAPSED 5-26  
   SYS\_ERRNO 5-23  
   SYS\_FLEN 5-19  
   SYS\_GET\_CMDLINE 5-24  
   SYS\_HEAPINFO 5-25  
   SYS\_ISERROR 5-17  
   SYS\_ISTTY 5-18  
   SYS\_OPEN 5-12

SYS\_READ 5-16  
 SYS\_READC 5-17  
 SYS\_RENAME 5-20  
 SYS\_SEEK 5-18  
 SYS\_SYSTEM 5-22  
 SYS\_TICKFREQ 5-26  
 SYS\_TIME 5-21  
 SYS\_TMPNAM 5-19  
 SYS\_WRITE 5-15  
 SYS\_WRITEC 5-14  
 SYS\_WRITEO 5-14  
 SetCPSR, ARMulator function 4-7  
 SetNfiq, ARMulator function 4-26,  
   4-27  
 SetNirq, ARMulator function 4-26,  
   4-27  
 SetPC, ARMulator function 4-6  
 SetReg, ARMulator function 4-5  
 SetR15, ARMulator function 4-6  
 SetSPSR, ARMulator function 4-8  
 stackuse.c ARMulator model 3-3  
 \$statistics variable 4-35  
 stc, ARMulator function 4-18  
 StopExecution, ARMulator function  
   4-49  
 Supervisor mode  
   entering from debug 5-27  
 SWIs  
   debug interaction SWIs 5-27  
 SYS\_CLOCK 5-21  
 SYS\_CLOSE 5-14  
 SYS\_ELAPSED 5-26  
 SYS\_ERRNO 5-23  
 SYS\_FLEN 5-19  
 SYS\_GET\_CMDLINE 5-24  
 SYS\_GET\_HEAPINFO 5-25  
 SYS\_ISERROR 5-17  
 SYS\_ISTTY 5-18  
 SYS\_OPEN 5-12  
 SYS\_READ 5-16  
 SYS\_READC 5-17  
 SYS\_RENAME 5-20  
 SYS\_SEEK 5-18  
 SYS\_SYSTEM 5-22  
 SYS\_TICKFREQ 5-26  
 SYS\_TIME 5-21  
 SYS\_TMPNAM 5-19  
 SYS\_WRITE 5-15  
 SYS\_WRITEC 5-14

SYS\_WRITEO 5-14

## T

Terminology Glossary-1  
 ThumBit, ARMulator function 4-9  
 Timer 4-77  
 Time, ARMulator function 4-45  
 ToolConf 4-2, 4-63, 4-68  
 ToolConf\_Cmp 4-74  
 ToolConf\_Lookup 4-73  
 Tracer  
   configuring 2-10, 2-13  
   events 2-11  
   output to RDI log window 2-10  
 Tracer, interpreting output 2-6  
 tracer.c 4-35  
 tracer.c ARMulator model 3-3  
 Tracing, ARMulator 4-35

## U

Unhandled ADP\_Stopped exception  
   5-30  
 UnkRDIInfoUpcall, ARMulator 4-35  
 Upcalls, ARMulator 4-33  
   armul\_EventUpcall 4-37  
   ExceptionUpcall 4-34  
   UnkRDIInfoUpcall 4-35

## V

Variables  
   erno 5-23  
   \$memory\_statistics 4-62  
   \$memstate 2-27  
   \$statistics 2-27, 4-35  
   \$stop\_of\_memory 5-25  
   \$vector\_catch 5-29

## W

Wait state calculation 2-28  
 WriteByte, ARMulator function 4-39  
 WriteHalfWord 4-39

WriteWord, ARMulator function 4-39  
write, ARMulator function 4-25

## Z

Zero wait state memory model 2-26

## Symbols

\$memory\_statistics 4-62  
\$statistics variable 4-35  
\$top\_of\_memory debugger variable  
5-25  
\$vector\_catch debugger variable 5-29